Kodak

Trendsetter 400/800 III

Installation Procedure

Document Number
719-00784A-D

28 Feb 2008

Copyright 2008 Kodak. All rights reserved.

Revision History

Revision	Date	Author	Comments
1.0	26 Sep 2006	Andrew So	Draft
A	Nov 2006	Andrew So	First release
B	14 May 2007	Andrew So	Fixed typographical error in workstation static IP address
C	11 Oct 2007	Ken Johnston	Removed Operator Training appendix; replaced with reference to *Trendsetter 400/800, AL, CL, & NEWS Operator Onsite Training Checklist*.
D	29 Feb 2008	Janet Waterman	Add link to RSS information

Kodak

Trendsetter 400/800 III
Installation Procedure

CONTENTS

Revision History i

1. About This Document 1

2. Preparing for Installation 1
   - 2.1 Site Preparation 1
   - 2.2 Required Tools and Equipment 2
   - 2.3 Related Documents 2

3. Unpacking 3
   - 3.1 Crate and Contents Inspection 3
   - 3.2 Unpacking the Trendsetter Output Device 3
   - 3.3 Unpacking the Workstation and UDRC 4

4. Assembly and Configuration 4
   - 4.1 Initial Setup 4
   - 4.2 Thermal Head 5
   - 4.3 Adding Coolant and Air Filter 6
   - 4.4 UDRC Installation 6
   - 4.5 Workstation Installation and Configuration 6

5. Head Alignment Verification and System Testing 7

6. Cleanup 7

7. Remote Support System Setup 7

8. Installation Test Procedure 8

9. Operator Training 8

1. ABOUT THIS DOCUMENT

This document is a guide for a field engineer who is installing a Kodak® Trendsetter® 400/800 III device. It is assumed that the person following this document has completed training on installation of Trendsetter 400/800 III CTP devices.

2. PREPARING FOR INSTALLATION

2.1 Site Preparation

One month before the installation a presite inspection should be done to ensure a smooth and timely installation. Please refer to the site preparation guide for the output device that you are installing. *Site Preparation Guides* are located on the Installation page in TechPlanet, for example, http://techplanet.creo.com/output/computer_to_plate/trendsetter_3244/nav/install.htm

Prior to the installation date, obtain a copy of the signed, completed *Site Preparation Checklist* (Appendix B of the *Site Preparation Guide*) and confirm that the customer has completed the requirements, including:

- Acceptable air supply quality (correct pressure, no water or oil in supply line)
- Dedicated phone line or broadband Internet connection for remote support
- Network connections
- Electrical requirements
- Floor space requirements
- Trendsetter output device work area dimensions
- Weight and level floor requirements
- Environmental conditions
- UDRC requirements

2.2 Required Tools and Equipment

- Two or three ½-inch sockets for opening crates (for air shipments only)
- Metric hex key set
- Screwdrivers
- Grounding wrist strap
- Loctite® adhesive
- Installation floor plan
- Vacuum for final cleanup
- Printed copy of the *Trendsetter 400/800, AL, CL, & NEWS Operator Onsite Training Checklist* (73-00145A—see "Related Documents")
- Forklift (as specified in the *Site Preparation Guide*) and operator for removing the Trendsetter output device from its crate
- Metric and imperial wrenches
- Multimeter
- Razor knife
- Spirit level for leveling device
- Cleaning rags and solutions (99 percent isopropyl alcohol and liquid soap)
- Service dongle

2.3 Related Documents

- *Trendsetter 400/800, AL, CL, & NEWS Operator Onsite Training Checklist* (73-00145A)

  http://techplanet.creo.com/output/computer_to_plate/trendsetter_3244/nav/install.htm#install_procs
- *Trendsetter 400/800 III Site Preparation Guide* (707-00566A)

  http://techplanet.creo.com/output/computer_to_plate/trendsetter_3244/nav/install.htm#site_prep
- *Trendsetter ContinuousLoad Site Preparation Guide* (707-00568A)

  http://techplanet.creo.com/output/computer_to_plate/trendsetter_cl/nav/install.htm#site_prep
- *Trendsetter Autoloader Site Preparation Guide* (707-00567A)

  http://techplanet.creo.com/output/computer_to_plate/trendsetter_al/nav/install.htm - site_prep
- *UDRC Site Preparation Guide* (725-00089A)

  http://techplanet.creo.com/output/heads/debris_removal/nav/install.htm#site_prep
- *Thermal Head 1.7 Installation Procedure* (77-0047A)

  http://techplanet.creo.com/output/heads/thermal/nav/install.htm#install_procs
- *Thermal 2 Head Installation Procedure for Trendsetter output devices* (719-00585A)

http://techplanet.creo.com/output/heads/thermal_2/nav/install.htm#install_procs

- *UDRC Installation Procedure* (750-00091A)

  http://techplanet.creo.com/output/heads/debris_removal/nav/install.htm#install_procs

- *GMCE Intel Pro/1000 MT Server Adapter Installation, Configuration and Testing* (719-00735A)

  http://techplanet.creo.com/output/device_control/print_console/content/docs/719-00735A-EN-A.pdf

- *CFL Setup Guide* (http://techplanet.creo.com/output/device_control/feature_licensing/content/docs/CFL_setup_guide.pdf)

- *Trendsetter 400/800 III, AL, CL Installation Test Procedure (701-00037A)*

  http://techplanet.creo.com/output/computer_to_plate/trendsetter_3244/nav/install.htm#accept

3. UNPACKING

Carefully open all crates and boxes.

Throughout the unpacking process, check for any signs of damage and notify immediately to Kodak immediately about any problems..

3.1 Crate and Contents Inspection

Inspect all delivered crates and boxes:

- Look for signs of damage from moisture, improper packing, tipping, dropping, stacking, and so on of crates, or any other sign of mishandling.
- Verify the contents of the crate and boxes according to the shipping label.
- Report any problems immediately to both Kodak and the delivery company.

3.2 Unpacking the Trendsetter Output Device

1. Open the shipping crate to allow access to the front and back of the device.

WARNING: Carefully unwrap the packaging from the system to minimize static discharge from tapes and plastic.

2. Inspect all contents for damage and record any problems on the Installation Report.
3. Remove boxes and other items that are not attached to the device from the crate.
4. Remove enough of the packaging from the top and front of the Trendsetter output device so that:
   - The lower-front panel can be hinged up.
   - The forklift slots are visible.

WARNING: All Trendsetter output devices must have the front panel open or removed to prevent damage to the panels while the device is being moved.

5. Measure 80 cm (30 in.) from the tip of the forks on the forklift and mark this location on the forks with tape or another method.

Note: The forklift must have a minimum 1,365 kg (3,000 lb.) capacity, the width of the forks must not exceed 15 cm (6 in.), and the span should be 51 cm (20 in.).

6. Slowly and carefully, slide the forks in to a depth of *80 cm (30 in.) maximum* (so the forks do not damage the back panel).

   If you need more clearance between the open panel and the forklift:

   - Remove the spring clips from one end of the gas struts.
   - Detach the struts.
   - Hinge the panel up higher.

7. Lift the device clear of the crate and gently lower the device onto its wheels.
8. Reinstall the gas struts and clips for the front panel if they were removed.
9. Close the front panel and move the Trendsetter output device to its permanent location.

3.3 Unpacking the Workstation and UDRC

1. Open the shipping crates and remove the contents.
2. Verify the contents, inspect for damage, and record any problems.
3. Move the workstation and other components to the permanent location using a dolly if one is available.
4. Unpack the workstation and other components.
5. Remove the packing material from the working area.

4. ASSEMBLY AND CONFIGURATION

4.1 Initial Setup

1. Remove any remaining packaging from around the top of the Trendsetter output device.
2. For a base Trendsetter, install the glass load ramp.
3. For Trendsetter AL and CL, remove the brackets holding the unload table in the upright position at the back of the output device.
4. Lower the unload table to its horizontal position.
5. If there is a rotator, use the brackets from step 3 to secure the rotator to the back panel.

6. Open the lower-front panel.
7. Remove the foam from under the drum and from both ends of the trailing edge bar.
8. Cut the white cable ties from the bottom of the picker at both ends. (Trendsetter AL only)
9. Close the front panel.
10. Release the latch at the lower-left corner of the bay door by lifting the arm upwards with a slim tool. (Trendsetter AL only)
11. Hold the arm in this position while you open the bay door. (Trendsetter AL only)
12. Cut the white cable ties at the top of the picker at both ends. (Trendsetter AL only)
13. Make sure the unload table is down so that the top side-trim panels can be removed.
14. To remove the top side-trim panels: (Trendsetter AL and CL only)
    - Use a flat screwdriver to unlatch the front of the panels.
    - Lift up the panel at the front and push it towards the back of the device to unhook the back of the panel.
15. Connect the air to the Trendsetter device and regulate the pressure down to 80 psi for Base, or 90 psi for AL and CL, with the adjustment valve on the back of the machine.
16. Connect the power to the Trendsetter device (200–240 V) to ground the device.
17. Level the Trendsetter:
    - Adjust the height of the attached feet to level the Trendsetter.
    - Ensure the machine is elevated off of the casters.
    - Ensure that the frame has not twisted due to excessive height differences between the feet.

4.2 Thermal Head

The Trendsetter output devices are now shipped from the factory with the thermal heads installed.

1. To access the thermal head:
    - For a base device, open the top panel to access the screws holding the rear panel in place.
    - For AL and CL devices, make sure the top side-trim panels are removed to access the screws holding the rear panel in place.
2. Remove the screws and rear panel.
3. Make sure all cables are secure at both ends.
4. Remove the holding brackets that hold the head and the carriage in place.
5. Inspect for any shipping damage and note on the Installation Service Report.

6. Make sure that:
   - The locking cam holds the head tightly in place.
   - All cables, hoses and the cable carrier are connected to the head.

4.3 Adding Coolant and Air Filter

1. To access the cooling tank:
   - Remove the panel from the fan box—push to release it.
   - Remove the rear-side panel by loosening or removing the four screws through the keyhole slots in the panel
2. Use the funnel to add coolant to the upper level marked on the tank.

   Note: You will have to add more coolant after the device is turned on because the coolant level will drop.
3. Install the intake air filter in the fan box.

4.4 UDRC Installation

The UDRC is standard on Trendsetter 400/800 III.

Refer to *UDRC Installation Procedure* (750-00091A).

4.5 Workstation Installation and Configuration

1. Assemble the workstation according to the vendor installation document provided with the workstation.
2. Check that the customer AC receptacle is wired correctly (see *Site Preparation Guide*).
3. If a UPS is available, plug the UPS into the AC main and connect the workstation to the UPS. Otherwise, plug the workstation power into the AC receptacle.
4. Plug in the navy blue customer dongle shipped with the workstation.
5. Connect the workstation to the network and phone line.
6. Connect the blue CAT 5E shielded cable between the Trendsetter and the Intel® PRO/100 MT Server Adapter.
7. Turn on the workstation.
8. Log in under the Administrator account.
9. The workstation is preconfigured with a static IP address 192.168.100.209 and subnet mask 255.255.255.128 for the GMCE connection. Consult with the customer's IT department about the IP addressing scheme used in their network to make sure there is no conflict.
10. If there is a conflict, follow the instructions in Section 2.3 "*Configuring the Adapter*" in the document *GMCE Intel Pro/1000 MT Server Adapter Installation, Configuration and Testing* (719-00735A), for an alternate IP address arrangement.

11. The workstation should be preinstalled with the controlled release (CR) for the output device connecting to it. If this is not the case, install the correct CR package.

12. Insert the Site Installer CD that is shipped with the Trendsetter device into the CD-ROM drive of the computer. The CD should run automatically. If it does not, run **Setup.exe** from the CD drive. This utility will copy the NVS parameters used in the factory to the device workstation.

13. Follow the prompts to complete the installation.

    You will be prompted to enter a secondary backup location—configure an accessible network location. The system will automatically backup the GMCE NVS parameters to this location to guard against accidental loss of the NVS parameters.

14. Install the Customer Device License if it has not already been installed on the workstation. You can find the Device License on the Site Installer CD or by doing a search on to http://master.creo.com/cflwebgenerator/. For more information, refer to the CFL Setup Guide on Techplanet. (http://techplanet.creo.com/output/device_control/feature_licensing/content/docs/CFL_setup_guide.pdf)

15. Turn on the Trendsetter and verify that the device is communicating with the workstation.

5. HEAD ALIGNMENT VERIFICATION AND SYSTEM TESTING

Refer to the *Thermal Head 1.7 Installation Procedure* (77-0074A) or *Thermal 2 Imaging Head Installation Procedure* (719-00585A) to verify the head alignment.

If there are problems, contact the Response Centre.

6. CLEANUP

1. Vacuum the inside of the device.
2. Replace all panels.
3. Clean the device exterior.
4. For a base Trendsetter:
   - Clean the glass load ramp.
   - Install the Plate Alignment Labels on the glass load ramp or load table. Refer to the procedures on TechPlanet at http://techplanet.creo.com/output/computer_to_plate/trendsetter_3244/nav/install.htm
5. Remove all packing material.
6. Vacuum the surrounding area.

7. REMOTE SUPPORT SYSTEM SETUP

See the configuration information on the Remote Support System (RSS) TechPlanet site at http://techplanet.creo.com/software_solutions/networking_os/rss/nav/proced.htm

8. INSTALLATION TEST PROCEDURE

1. Perform the ITP as described in the *Trendsetter 400/800 III, AL, CL Installation Test Procedure* (701-00037A) and complete the *Trendsetter 400/800 III Installation Test Procedure Checklist* (732-00120A).

2. Send the signed ITP checklist to Kodak for confirmation of device acceptance.

9. OPERATOR TRAINING

Before leaving the customer site, go over the *Trendsetter 400/800, AL, CL, & NEWS Operator Onsite Training Checklist* (73-00145A—see “Related Documents” on page 2) with the operators so that they are clear on how to use and maintain the Trendsetter output device.