Kodak

Magnus XLF 80

Output Devices
Model MTA

Safety Guide
English

761-00048A-EN Rev A

Copyright

© Kodak, 2007. All rights reserved.

This document is also distributed in Adobe Systems Incorporated's PDF (Portable Document Format). You may reproduce the document from the PDF file for internal use. Copies produced from the PDF file must be reproduced in whole.

Trademarks

Kodak, Creo, and Magnus are trademarks of Kodak.

Adobe, Acrobat, Adobe Illustrator, Distiller, Photoshop, PostScript, and PageMaker are trademarks of Adobe Systems Incorporated.

Apple, AppleShare, AppleTalk, iMac, ImageWriter, LaserWriter, Mac OS, Power Macintosh, and TrueType are registered trademarks of Apple Computer, Inc. Macintosh is a trademark of Apple Computer, Inc., registered in the U.S.A. and other countries.

PANTONE, Hexachrome, PANTONE Hexachrome, and PANTONE MATCHING SYSTEM are the property of Pantone, Inc.

PEARL, PEARLdry, PEARLgold, PEARLhdp, and PEARLsetter are registered trademarks of Presstek, Inc.

XEROX is a trademark of XEROX CORPORATION.

FCC Compliance

Any Kodak equipment referred to in this document complies with the requirements in part 15 of the FCC Rules for a Class A digital device. Operation of the Kodak equipment in a residential area may cause unacceptable interference to radio and TV reception, requiring the operator to take whatever steps are necessary to correct the interference.

Equipment Recycling



In the European Union, this symbol indicates that when the last user wishes to discard this product, it must be sent to appropriate facilities for recovery and recycling.

Contact your local Kodak representative or refer to http://www.kodak.com/go/recycle for additional information on the collection and recovery programs available for this product.

Limitation of Liability

The product, software or services are being provided on an “as is” and “as available” basis. Except as may be stated specifically in your contract, Kodak expressly disclaims all warranties of any kind, whether express or implied, including, but not limited to, any implied warranties of merchantability, fitness for a particular purpose and non-infringement.

You understand and agree that, except as may be stated specifically in your contract, Kodak shall not be liable for any direct, indirect, incidental, special, consequential or exemplary damages, including but not limited to, damages for loss of profits, goodwill, use, data or other intangible losses (even if Kodak has been advised of the possibility of such damages), resulting from: (i) the use or the inability to use the product or software; (ii) the cost of procurement of substitute goods and services resulting from any products, goods, data, software, information or services purchased; (iii) unauthorized access to or alteration of your products, software or data; (iv) statements or conduct of any third party; (v) any other matter relating to the product, software, or services.

The text and drawings herein are for illustration and reference only. The specifications on which they are based are subject to change. Kodak may, at any time and without notice, make changes to this document. Kodak assumes no liability for technical or editorial errors or omissions made herein, and shall not be liable for incidental, consequential, indirect, or special damages, including, without limitation, loss of use, loss or alteration of data, delays, or lost profits or savings arising from the use of this document.

http://graphics.kodak.com/

Internal 761-00048A-EN Rev A

Revised January 2008

Contents

1 Operator Safety 1

What Is in This Document 2
For More Information 2
Installing, Operating, and Maintaining the Platesetter 2
Using Safety Messages to Avoid Hazardous Situations 3
Recognizing Different Levels of Hazard 4
Danger Safety Messages 4
Warning Safety Messages 5
Caution Safety Messages 6
Notices 6
In Case of Fire 6
Safety Features 7
The Interlock System 7
Power/Emergency Stop Switches 9
Emergency Stop Buttons 10

A Labels 11

Overview 12
Description of Labels on the Platesetter 12
Identification and Regulatory Compliance Labels 13
Laser Safety Labels on the Access Panels 15
Electrical, Mechanical, and General Safety Labels 16
Description of Labels on the Thermal Imaging Head 21
Identification and Regulatory Compliance Labels 21
Imaging Head Aperture Label 22
Laser Hazard/Class 4 Laser Product Label/Radiation Output 22
Description of Labels on the Debris Removal Component 23
Identification, Configuration, and Regulatory Compliance Labels 24
Configuration Labels 24
Airborne Emissions Labels 24
Label Locations 26
Location of Labels on the Magnus XLF 80 26
Location of Labels on the Thermal Imaging Head 30

B Regulatory Compliance 31

Regulatory Approval Model Designation 32
Compliance With Standards for Electrical and Mechanical Safety 32
EC Declaration of Conformity for the Platesetter 33
EC Declaration of Conformity for the Filtration Unit 34
Compliance With Standards for Laser Safety 34
Compliance With Standards for Electromagnetic Interference and Electromagnetic Compatibility 35
Compliance With Standards for Noise Emissions 35

Index 37

1 Operator Safety

What Is in This Document 2
For More Information 2
Installing, Operating, and Maintaining the Platesetter 2
Using Safety Messages to Avoid Hazardous Situations 3
In Case of Fire 6
Safety Features 7

What Is in This Document

This document contains the safety information that operators require to operate and maintain a Kodak® Magnus™ XLF 80 Platesetter (model MTA), including regulatory compliance information. Where appropriate, it refers you to additional documentation about standards for electrical, mechanical, and laser safety. It also describes labels that are intended as safety reminders for Kodak service representatives.

This document includes the following sections:

- The *Installing, Operating, and Maintaining the Platesetter* section provides an overview of the tasks that operators can safely perform.
- The *Using Safety Messages to Avoid Hazardous Situations* section describes situations that can result in serious injury or death for the operator. This section also describes situations that can result in damage to the platesetter or its options.
- The *In Case of Fire* section provides information about what to do if there is a fire in the platesetter.
- The *Safety Features* section describes the various safety features built into the platesetter for your protection: the interlock system, the power/emergency stop switch, and the emergency stop button.
- *Appendix A, Labels* describes the labels that are located on the platesetter to help you safely operate your imaging system.
- *Appendix B, Regulatory Compliance* lists the safety standards for which the platesetter was designed, tested, and evaluated for compliance.

For More Information

If you have other questions about the safe use of the platesetter, contact a service representative. The service representative may request the serial number, which you can find on the dataplate label at the back of the platesetter (for an example of this label, see page 13).

Visit http://graphics.kodak.com/ for documentation, training courses, downloads, and service and support contacts.

Installing, Operating, and Maintaining the Platesetter

Installation

A service representative must install the platesetter and perform the initial setup. Ensure that you are in compliance with the operating environment and connection requirements specified in the latest version of the site preparation guide for your platesetter.

Operation

Before using the platesetter, you must read this guide and understand it. When using the platesetter, you must follow all of the safety messages and recommended procedures for device operation and troubleshooting. These safety messages and procedures are in help topics that are available through the **Help** menu in the Print Console software and in the visual reference guide for your platesetter.

This safety guide must be accessible to anyone who operates the platesetter.



WARNING: Failure to read, understand, and follow the information in this guide may result in the incorrect operation of this product and could create a dangerous situation. This could result in serious injury as well as damage to the platesetter.

Maintenance

The maintenance procedures that an operator can safely perform are described in help topics that are available through the **Help** menu in the Print Console software and in the visual reference guide for your platesetter. They include:

- Cleaning exterior surfaces
- Cleaning the edge detection strip
- Cleaning the plate roller
- Replacing the particulate filter for the compressed air supply on the platesetter
- Replacing the air intake filters for the power box, heat exchanger, and rear fans
- Replacing the debris removal filter

Only a service representative should perform other maintenance procedures and all service work.

Using Safety Messages to Avoid Hazardous Situations

Paragraphs labelled **DANGER**, **WARNING**, and **CAUTION** provide safety information. Disregarding danger, warning, and caution safety messages can result in personal injury or death to you or to others in the vicinity of the platesetter. Paragraphs labelled **NOTICE** alert you to the possibility of damage to the platesetter.

The dangers, warnings, cautions, and notices described in the next sections apply to the operation and maintenance of the platesetter and its options. There may also be dangers, warnings, cautions, and notices that apply to other prepress equipment connected to the platesetter. See the documentation provided by the manufacturer of that equipment for relevant safety information.

Recognizing Different Levels of Hazard

DANGER: The use of the safety alert symbol with the signal word "danger" indicates an imminently hazardous situation, which, if not avoided, will result in serious injury or death. This does not alert you to potential damage to the output device unless personal injury risks are associated with the accident.

WARNING: The use of the safety alert symbol with the signal word "warning" indicates a potentially hazardous situation, which, if not avoided, could result in serious injury or death. This does not alert you to potential damage to the output device unless personal injury risks are associated with the accident.

CAUTION: The use of the safety alert symbol with the signal word "caution" indicates a potentially hazardous situation, which, if not avoided, may result in minor or moderate injury. This may also alert you to unsafe practices. This does not alert you to potential damage to the output device unless personal injury risks are associated with the accident.


NOTICE: The use of the signal word "notice" indicates a situation which, if not avoided, could result in damage to the output device.

Danger Safety Messages

DANGER: Do not tamper with the access panel interlock system. Never attempt to operate the output device with any of the access panels open, and never attempt to open or remove access panels while the output device is imaging plates. Tampering with the interlock system can result in serious injury from visible and invisible high-powered laser radiation and/or moving mechanical parts.

DANGER: Do not perform unauthorized repairs or make modifications. Unauthorized panel removal, repairs, or changes made to the output device can expose you to visible and invisible high-powered laser radiation, moving mechanical parts, and/or electrical shock, which will result in serious injury or death.


DANGER: The Safety Interlock Override (SIO) switch is for use only by a service representative. Unauthorized use can expose you to serious danger from visible and invisible high-powered laser radiation, moving mechanical parts, and/or electrical shock, which could result in serious injury or death.



Safety Interlock Override (SIO) switch

DANGER: The service access panels can be removed only by a service representative. Unauthorized panel removal can expose you to serious danger from visible and invisible high-powered laser radiation and/or moving mechanical parts, which could result in serious injury or death.

DANGER: Do not remove any covers or panels bearing the laser noninterlocked panel label (see below). These areas can expose you to serious danger from visible and invisible high-powered laser radiation and/or moving mechanical parts, which could result in serious injury or death.



DANGER: Do not remove any covers bearing the hazardous voltage label (see below). These areas contain high-voltage components that can cause severe electrical shock, which could result in serious injury or death.



Warning Safety Messages

WARNING: When opening access panels, keep hands away from moving parts until the rotating drum comes to a complete stop. Mechanical hazards associated with the output device can result in serious injury and/or damage to your output device.

WARNING: Particulate emissions that are not properly filtered can endanger your health. For a list of airborne emissions that pertain to the media you are using, see the manufacturer's Material Safety Data Sheet (MSDS) or contact the manufacturer or distributor directly.

WARNING: Do not use a debris removal particulate filter with a damaged gasket and do not attempt to image printing media with a depleted filter. Failure to heed these warnings could result in exposure to airborne emissions in excess of applicable regulatory limits and in possible discomfort, illness, injury, and/or disability.

WARNING: Use only qualified media. Using unqualified media may expose you to noxious gaseous emissions in excess of applicable regulatory limits. This may result in discomfort, illness, injury, and/or disability.

WARNING: Do not let water or other liquids run freely into the output device. This can result in serious injury from electrical shock as well as damage to your output device.



WARNING: Do not use chemical solvents or aggressive cleaning solutions for cleaning the compressed air supply particulate filter bowl. This can cause cracking or crazing damage to the plastic parts. When damaged plastic parts are exposed to high air pressure, these parts may explode and cause serious injury and/or damage to the output device.



WARNING: Be careful handling the magnetic clamps if you have a pacemaker. Operators with implanted cardiac pacemakers should ensure that magnetic clamps are kept more than 7 cm (2.75 in.) away from their pacemaker. If you have additional concerns, consult your physician and/or the manufacturer of your implant.



WARNING: Turn off the compressed air supply when working on the air supply filters. Failure to turn off the compressed air supply before inspecting or replacing a compressed air supply filter will result in the following:

- High-pressure air to be present in the filter elements and bowl, making disassembly difficult and dangerous. This could result in possible serious injury to you or damage to the output device from flying parts
- A very loud noise that could damage your hearing

Caution Safety Messages



CAUTION: Wear protective gloves when handling plates. Plate edges can be sharp. Failure to wear protective gloves can result in injury.



CAUTION: Wear protective gloves when handling the magnetic clamps. Otherwise, you may pinch your fingers between the trailing-edge clamps and the drum.

Notices


NOTICE: When placing or sliding a trailing-edge clamp on the drum, ensure that the steel tabs on the clamp are centered on the steel straps on the drum. The clamp tabs can damage the drum surface if the tabs are not aligned properly.

NOTICE: Remove all slip sheets and packaging material from both the back and front of plates before you image them in the platesetter. Otherwise, the thermal laser could ignite the paper, causing a fire in the output device.

In Case of Fire

If there is a fire in the platesetter, immediately turn off the rotary Power/Emergency Stop switch.

NOTICE: Remove all slip sheets and packaging material from both the back and front of plates before you image them in the platesetter. Otherwise, the thermal laser could ignite the paper, causing a fire in the output device.



Safety Features

The platesetter has these safety features:

- An interlock system
- A Power/Emergency Stop switch
- Emergency Stop buttons

The Interlock System

Platesetters are equipped with an interlock system. An interlock system prevents the activation of a piece of equipment when a protective door is open or some other hazard exists. In platesetters, if you open or remove an interlocked door or panel while the platesetter is operating, the platesetter:

- Removes power from the laser, to protect you against injury from visible and invisible high-powered laser radiation
- Halts all mechanical activity, to protect you against injury from moving mechanical parts

Visible and Invisible High-Powered Laser Radiation

Laser emissions from an exposure head are invisible to the naked eye and are very dangerous if they contact skin or eyes. If you open or remove an access panel while the platesetter is operating, the interlock system removes power from the laser.

DANGER: Never attempt to operate the output device with any of the access panels open, and never attempt to open or remove access panels while the output device is imaging plates. Tampering with the interlock system can result in serious injury or death from visible and invisible high-powered laser radiation and/or moving mechanical parts.

There are labels on all the access panels that have interlock switches to protect you against visible and invisible high-powered laser radiation. See *Laser Interlocked Panel Label* on page 15.

Moving Mechanical Parts

The platesetter has a drum that revolves inside the output device. The plates are loaded, wrapped onto the drum, imaged, and unloaded.

The drum normally revolves up to 400 times per minute. If an object hits the revolving drum, the object may become lodged inside the output device and cause damage, including damage to the safety system, thermal imaging head, or protective enclosure. If you open or remove an access panel while the platesetter is operating, the interlock system halts all mechanical activity.

To access the drum for regular preventative maintenance or troubleshooting, you must open the rear hood of the platesetter. This hood is secured with a solenoid lock (see *Solenoid Lock Label* on page 18).

There are two ways to unlock the rear hood:

- Click **Unlock** in the Print Console device control software. If any jobs are being imaged when you click **Unlock**, Print Console displays a message asking if you want to cancel them before it sends the unlock command. If the drum is in motion when you click **Unlock**, the solenoid lock normally does not release until the drum comes to a complete standstill. If you see *any* mechanical movement when you open the rear hood, the platesetter must be repaired.
- Turn the power off and wait five seconds before opening the rear hood. The solenoid lock releases as soon as the power is disconnected. If the drum is in motion when you turn off the power, it normally stops revolving within five seconds of the lock being released. If you see mechanical movement after five seconds has elapsed since turning off the power to the platesetter, the platesetter must be repaired.

In either case, if you see mechanical movement that indicates the output device requires repair, do the following actions:

1. Keep your hands away from the moving parts.
2. Turn the rotary Power/Emergency Stop switch to the **Off** position (see page 9).
3. Close the rear hood.
4. Contact your service representative as soon as possible.

When the lock is released, confirm that the drum has stopped revolving before you start your maintenance or troubleshooting procedure (see *Keep Hands Out Label* on page 18).

Because exposure to a revolving drum can result in serious injury to the operator, service representative, or others in the vicinity of the output device, make sure that you comply with these drum safety messages:



DANGER: Do not tamper with the access panel interlock system. Never attempt to operate the output device with any of the access panels open, and never attempt to open or remove access panels while the output device is imaging plates. Tampering with the interlock system can result in serious injury from visible and invisible high-powered laser radiation and/or moving mechanical parts.



WARNING: When opening access panels, keep hands away from moving parts until the revolving drum comes to a complete stop. Mechanical hazards associated with the output device can result in serious injury.

NOTICE: Do not leave any object, tool, or part inside or on the output device enclosure. If an object becomes lodged in the output device, it may damage the output device.

Power/Emergency Stop Switches

The Power/Emergency Stop switch disconnects power to the platesetter. The switch is located on the outside of the output device.

Note: If the Power/Emergency Stop switch is red with a yellow background, it disconnects power to the entire platesetter system. If the switch is black, it disconnects power only to the device on which it is located.




Figure 1: Power/Emergency Stop switch on Magnus XLF 80 platesetters

Regular Operation

When you are instructed to turn off the power to the platesetter for a maintenance procedure, turn the Power/Emergency Stop switch counterclockwise to the **Off** position. You can secure the switch in the **Off** position with a padlock to prevent another person from turning on the device while you are performing troubleshooting or maintenance procedures. See Figure 2.

Emergency Shutdown

If the Emergency Stop button is not accessible, turn the Power/Emergency Stop switch counterclockwise to the **Off** position. The switch disconnects power to the platesetter, which means that you cannot access information about the status of the output device.




Figure 2: Turn the switch counterclockwise to turn off the power

Emergency Stop Buttons

The Emergency Stop button stops laser operation and mechanical movement, but the power remains connected. You can continue to access information about the status of the platesetter. Use this button to stop laser operation and mechanical movement in an emergency situation.Buttons are located inside the output device and in the exterior locations shown next.

If you press this button, you must reset it before the output device can return to normal operation. To reset the button, rotate it 90° clockwise and reset the platesetter.




Figure 3: Emergency Stop buttons on the Magnus XLF 80

A

Labels

Overview 12
Description of Labels on the Platesetter 12
Description of Labels on the Thermal Imaging Head 21
Description of Labels on the Debris Removal Component 23
Label Locations 26

Overview

This appendix contains information about the labels that are located on the:

- Platesetter (next section)
- Thermal imaging head (see page 21)
- Debris removal component (see page 23)

These labels are intended to assist you in safely operating your output device. They include information about:

- Device identification
- Compliance with various regulatory standards
- Laser safety
- Mechanical, electrical, and general safety

All the labels described in this appendix are in areas where they can be seen by platesetter operators. The labels that are intended primarily for the safety of service representatives are not included, except for those that are located in areas where operators can also see them.

Description of Labels on the Platesetter

Type of Label	Label Name	Illustration	Location
Identification and regulatory compliance	Dataplate	page 13	page 26
	Class 1 laser product	page 14	page 26
	Center for Devices and Radiological Health (CDRH) compliance statement	page 14	page 26
	Federal Communications Commission (FCC) compliance statement	page 14	page 26
Laser safety labels on the access panels	Laser interlocked panel	page 15	page 26 page 27
	Laser noninterlocked panel	page 15	page 29

Type of Label	Label Name	Illustration	Location
Electrical, mechanical, and general safety	High touch current	page 16	page 26
	Hazardous voltage	page 16	page 26 page 27
	Fuse replacement	page 16	
	Outlet for heat exchanger or chiller	page 17	next to electrical outlet
	Outlet for debris removal component	page 17	
	Two power supply cords (warning for service)	page 17	page 26
	Solenoid lock	page 18	page 26
	Keep hands out until drum has stopped rotating warning	page 18	page 27
	Safety interlock override (danger for service representatives)	page 19	page 26
	Beware of moving parts when interlock deliberately overridden (warning for service)	page 19	page 27
	Backbone release switch (warning for service)	page 20	page 27
	Maximum PSI/BAR	page 20	page 26
	Pacemaker warning label	page 21	page 27

Identification and Regulatory Compliance Labels

The identification and regulatory compliance labels are located on the power entry box below the Power/Emergency Stop switch.

Dataplate Label

This label is located on the power entry panel, below the Power/Emergency Stop switch. See *Labels on the exterior panels at the rear of the Magnus XLF 80* on page 26. When you call a service representative, you may be asked to find the serial number for your output device on this label.




Figure 4: Dataplate label for Magnus XLF 80 platesetters

Class 1 Laser Product Label

This label is located on the power entry panel, below the Power/Emergency Stop switch. See *Labels on the exterior panels at the rear of the Magnus XLF 80* on page 26.



Figure 5: Class 1 laser product label

Center for Devices and Radiological Health (CDRH) Compliance Statement Label

This label is located on the power entry panel, below the Power/Emergency Stop switch. See *Labels on the exterior panels at the rear of the Magnus XLF 80* on page 26.




Figure 6: CDRH compliance statement label

Federal Communications Commission (FCC) Compliance Statement Label

This label is located on the power entry panel, below the Power/Emergency Stop switch. See *Labels on the exterior panels at the rear of the Magnus XLF 80* on page 26.




Figure 7: FCC compliance statement label

Laser Safety Labels on the Access Panels

Laser Interlocked Panel Label

These labels are located beside the safety interlock switches inside the interlocked protective housing. See *Labels on interior components that can be seen when the Magnus XLF 80 rear hood and panels are open* on page 27.

DANGER: Do not tamper with the access panel interlock system. (See *The Interlock System* on page 7.) Tampering with the interlock system can result in serious injury from visible and invisible high-powered laser radiation and/or moving mechanical parts.



Figure 8: Laser interlocked panel label

Laser Noninterlocked Panel Label

The laser noninterlocked panel label is located on the tool-secured service access covers or panels that provide laser safety. See *Location of laser noninterlocked panel labels on the Magnus XLF 80* on page 29.

DANGER: The service access covers or panels can be removed only by a service representative. Do not remove covers or panels bearing this label. Accessing the areas protected by these covers or panels can expose you to serious injury from visible and invisible high-powered laser radiation and/or moving mechanical parts.




Figure 9: Laser noninterlocked panel danger label

Electrical, Mechanical, and General Safety Labels

High Touch Current Label

This label is located on the power entry panel below the Power/Emergency Stop switch. See *Labels on the exterior panels at the rear of the Magnus XLF 80* on page 26.



Figure 10: High touch current label

Hazardous Voltage Label

This label is found in these locations:

- This label is located on the power entry panel below the Power/Emergency Stop switch. See *Labels on the exterior panels at the rear of the Magnus XLF 80* on page 26.
- In the fan box, on the service access cover for the junction box. See *Labels on the debris removal unit and fan* on page 28.
- In the heat exchanger unit, on the service access cover for the junction box. See *Labels on the debris removal unit and fan* on page 28.



DANGER: Service access covers can be removed only by an authorized service representative. Do not remove covers bearing this label as these areas contain high-voltage components that can cause severe electrical shock, which could result in serious injury or death.



Figure 11: Hazardous voltage label

Fuse Replacement Label

This label is located adjacent to the fuses in the power box that operators can replace under the direction of the Kodak Response Center.




Figure 12: Fuse replacement label

Label on Outlet for Heat Exchanger/Chiller

This label is located next to the electrical outlet dedicated for the chiller or heat exchanger.




Figure 13: Heat exchanger/chiller electrical rating

Label on Outlet for Debris Removal Component

This label is located next to the AC outlet dedicated for the debris removal component in your platesetter system.



Figure 14: Label that identifies outlet for the MDRC component

Two Power Supply Cords Label

This label is located on the power entry panel below the Power/Emergency Stop switch. See *Labels on the exterior panels at the rear of the Magnus XLF 80* on page 26.




Figure 15: Two power supply cords label

Solenoid Lock Label

This label is located beside each latch on panels that have solenoid locks. See *Labels on the exterior panels at the rear of the Magnus XLF 80* on page 26.




Figure 16: Solenoid lock label

Keep Hands Out Label

This label is located on each end of the tilt bar that is located behind the rear panels near the drum. See *Labels on interior components that can be seen when the Magnus XLF 80 rear hood and panels are open* on page 27.



Figure 17: Keep hands out label

Safety Interlock Override Label (for Service Personnel)

This label is located beside the safety interlock override switch on the power box panel. See *Labels on the exterior panels at the rear of the Magnus XLF 80* on page 26.

DANGER: The service safety interlock override key switch is for use only by an authorized service representative. Unauthorized use can expose you to serious danger from visible and invisible high-powered laser radiation, moving mechanical parts, and/or electrical shock, which could result in serious injury or death.




Figure 18: Safety interlock override label

Beware of Moving Parts When Interlock Deliberately Overridden Label (for Service Personnel)

This label is located behind the front panel on both ends of the leading-edge clamp. See *Labels on interior components that can be seen when the Magnus XLF 80 rear hood and panels are open* on page 27.



Figure 19: Beware of moving parts when interlock deliberately overridden label

Backbone Release Switch Label (for Service Personnel)

The backbone release switch is for service use only, but is in an area where operators can see it. See *Labels on interior components that can be seen when the Magnus XLF 80 rear hood and panels are open* on page 27. It is located next to each of the two backbone release switches mounted on the back of the rear hood or on the punch assembly.




Figure 20: Backbone release switch label

Maximum PSI/BAR Label

This label is located near the compressed air inlet connector. See *Labels on the exterior panels at the rear of the Magnus XLF 80* on page 26.




Figure 21: Maximum PSI/BAR label

Pacemaker Warning Label

This label is located on the magnetic clamps. See *Labels on interior components that can be seen when the Magnus XLF 80 rear hood and panels are open* on page 27.

CAUTION: Operators with implanted cardiac pacemakers should keep magnetic clamps more than 7 cm (2.75 in.) away from their pacemaker. If you have additional concerns, consult your physician and/or the manufacturer of your implant.



Figure 22: Pacemaker warning label

Description of Labels on the Thermal Imaging Head

Type of Label	Label Name	Illustration	Location
Identification and regulatory compliance	Dataplate thermal 2 head	page 21	page 30
	Dataplate thermal 3 head	page 22	
Laser safety	Exposure head aperture	page 22	
	Laser hazard/Class 4 laser product/radiation output	page 23	

Identification and Regulatory Compliance Labels

Dataplate Label




Figure 23: Dataplate label for thermal imaging head model TH2




Figure 24: Dataplate label for thermal imaging head model TH3

Imaging Head Aperture Label

This label is located on top of the thermal imaging head protective housing, pointing to the shutter and aperture at the front of the thermal imaging head protective housing. See *Location of laser safety labels on the thermal imaging head* on page 30.



Figure 25: Exposure head aperture label

Laser Hazard/Class 4 Laser Product Label/Radiation Output

The laser hazard/Class 4 laser product /radiation output safety label is located on the back of the thermal imaging head protective housing. See *Location of laser safety labels on the thermal imaging head* on page 30. It will be one of the following examples, depending on the model.



Figure 26: Laser hazard/Class 4 laser product/Radiation output: thermal 1.7 head or thermal 2 head



Figure 27: Laser hazard/Class 4 laser product/Radiation output: thermal 3 head

Description of Labels on the Debris Removal Component

All Magnus XLF 80 platesetters require a Magnus Debris Removal Cabinet (MDRC).

Type of Label	Label Name	Illustration	Location
Identification, configuration, and regulatory compliance	Dataplate	page 24	page 28
	External venting option	page 24	
	BP configuration (external venting option)	page 24	
Airborne emissions	Particulate airborne emissions	page 24	
	Gaseous and particulate airborne emissions	page 26	

Identification, Configuration, and Regulatory Compliance Labels

Dataplate Label

This label is located on the front of the debris removal canister. See *Labels on the debris removal unit and fan* on page 28.




Figure 28: Dataplate label for Debris Removal Cabinet Model MDRC

Configuration Labels

The configuration label is located on the front of the debris removal canister. See *Labels on the debris removal unit and fan* on page 28.

BP Configuration Label




Figure 29: BP Configuration label

Airborne Emissions Labels

Particulate Airborne Emissions Label

The Particulate Airborne Emissions label (if applicable) warns you of the possible release of airborne emissions when imaging certain types of printing media.

Important: Do not attempt to use printing media that have not been qualified by Kodak.




Figure 30: Particulate Airborne Emissions label

Label Locations

Location of Labels on the Magnus XLF 80



Figure 31: Labels on the exterior panels at the rear of the Magnus XLF 80

For an illustration of these labels and more information, see:

- *Dataplate Label* on page 13
- *Class 1 Laser Product Label* on page 14
- *Center for Devices and Radiological Health (CDRH) Compliance Statement Label* on page 14
- *Federal Communications Commission (FCC) Compliance Statement Label* on page 14
- *High Touch Current Label* on page 16
- *Hazardous Voltage Label* on page 16
- *Two Power Supply Cords Label* on page 17
- *Solenoid Lock Label* on page 18
- *Laser Interlocked Panel Label* on page 15
- *Safety Interlock Override Label (for Service Personnel)* on page 19
- *Maximum PSI/BAR Label* on page 20




Figure 32: Labels on interior components that can be seen when the Magnus XLF 80 rear hood and panels are open

For an illustration of these labels and more information, see:

- *Laser Interlocked Panel Label* on page 15
- *Keep Hands Out Label* on page 18
- *Beware of Moving Parts When Interlock Deliberately Overridden Label (for Service Personnel)* on page 19
- *Backbone Release Switch Label (for Service Personnel)* on page 20
- *Pacemaker Warning Label* on page 21



Figure 33: Labels on the debris removal unit and fan

For an illustration of these labels and more information, see:

- *Dataplate Label* on page 24
- *BP Configuration Label* on page 24
- *Particulate Airborne Emissions Label* on page 24
- *Hazardous Voltage Label* on page 16




Figure 34: Location of laser noninterlocked panel labels on the Magnus XLF 80

For an illustration of this label and more information, see *Laser Noninterlocked Panel Label* on page 15.

Location of Labels on the Thermal Imaging Head




Figure 35: Location of laser safety labels on the thermal imaging head

For an illustration of these labels and more information, see:

- *Imaging Head Aperture Label* on page 22
- *Laser Hazard/Class 4 Laser Product Label/Radiation Output* on page 22
- *Dataplate Label* on page 21

B

Regulatory Compliance

Regulatory Approval Model Designation 32
Compliance With Standards for Electrical and Mechanical Safety 32
Compliance With Standards for Laser Safety 34
Compliance With Standards for Electromagnetic Interference and Electromagnetic Compatibility 35
Compliance With Standards for Noise Emissions 35

Regulatory Approval Model Designation

MTA is the regulatory approval model designation for the Magnus XLF 80 output device. The regulatory approval model designation name appears on the dataplate label (for an example of this label, see page 13) and all regulatory approval documents.

Compliance With Standards for Electrical and Mechanical Safety

The Magnus XLF 80 output device has been designed, tested, and evaluated for compliance with these electrical and mechanical safety standards:

- CSA 60950-1 *Information Technology Equipment —Safety—Part 1*
- UL 60950-1 *Information Technology Equipment—Safety—Part 1*
- EN 60950-1 *Information Technology Equipment—Safety—Part 1*
- EN 60204-1 *Safety of Machinery, Electrical Equipment of Machines*


The CSA International "cCSAus" mark on the dataplate label (for an example of this label, see page 13) indicates compliance with these standards:

- CSA 60950-1 *Information Technology Equipment —Safety—Part 1*
- UL 60950-1 *Information Technology Equipment—Safety—Part 1*

The CE mark on the dataplate label indicates compliance with the following directives:

- Low Voltage Directive 73/23/EEC
- Directive of Machinery 98/37/EC
- EMC Directive 89/336/EEC

EC Declaration of Conformity for the Platesetter



Kodak **Declaration of Conformity**

Kodak Graphic Communications Canada Company
Burnaby, Canada

We declare our sole responsibility that the product:

Product: **Imaging Device**
Product Name: **MAGNUS VLF**
Regulatory Model: **MTA**

to which this declaration relates is in conformity with the following standards and therefore bears the CE marking:

EN 60204-1 / 1997 +A1 Safety of Machinery, Electrical Equipment of Machines
EN 60825-1 / 1994 +A1 +A2 Safety of Laser Products (Class 1 Laser Product)
EN 60950-1 / 2001 Information Technology Equipment - Safety - Part 1: General Req.
EN 55011 Class A / 1998 +A1 +A2 EMC, Product Standard, Emission (CISPR 11)
EN 61000-3-3 / 1995+A1 EMC, Limitation of Voltage Fluctuations and Flicker In Low-Voltage Supply Systems For Equipment
EN 61000-6-1 / 2001 EMC, Generic Immunity Standard, Light-Industrial Environment

following the provisions of the applicable directives:

Machinery Directive 98/37/EC and amendments
Low Voltage Directive 73/23/EEC and amendments
EMC Directive 89/336/EEC and amendments

Supplementary Information:

- The product is assigned a regulatory model designation which denotes the regulatory aspects of the design. The regulatory model designation is the main product identifier in the regulatory documentation and test reports, and is marked on the product's dataplate label. The regulatory model designation should not be confused with the product name(s) for marketing purposes.
- The regulatory model designation includes the following options: ContinuousLoad, Autoloader, APL, Punch, TH2 and TH3.
- The product is rated 200-240 V AC, 50/60 Hz, 24 A (x2), cord connected, Class I.
- The product is high-powered (>1 kW) for professional use and is therefore exempt from the requirements of EN 61000-3-2.
- Kodak Graphic Communications Canada Company is registered to ISO 9001.

European Contact: Israel Sandler, Managing Director, Creo EMEA S.A., a subsidiary of Kodak, Waterloo Office Park, Building E-F, Drève Richelle 161, B-1410 Waterloo, Belgium, Phone +32.2.352 25 11, Fax +32.2.351 09 15.


Burnaby, 9 July 2007

Keith Poulin
Product Safety & Compliance

Kodak Graphic Communications Canada Company
3700 Gilmore Way • Burnaby • BC • Canada • V5G 4M1
Phone 604.451.2700 • Fax 604.437.9891

Figure 36: EC Declaration of Conformity for the platesetter

EC Declaration of Conformity for the Filtration Unit



Kodak **Declaration of Conformity**

Kodak Graphic Communications Canada Company
Burnaby, Canada

We declare our sole responsibility that the product:

Product: **Filtration Unit**
Product Name: **Universal Debris Removal Cabinet, Magnus VLF Debris Removal Cabinet,**
Regulatory Model: **UDRC, MDRC**

to which this declaration relates is in conformity with the following standards and therefore bears the CE marking:

EN 60950-1 / 2001 Information Technology Equipment - Safety - Part 1: General Req.
EN 55022 Class A / 1998 +A1 +A2 EMC, Product Standard, Emission (CISPR 22)
EN 55024 / 1998 +A1 +A2 EMC, Product Family Standard, ITE Immunity Characteristics - Limits and Methods of Measure
EN 61000-3-3 / 1995 +A1 EMC, Limitation of Voltage Fluctuations and Flicker In Low-Voltage Supply Systems For Equipment

following the provisions of the applicable directives:

Low Voltage Directive 73/23/EEC and amendments
Directive of Electromagnetic Compatibility 2004/108/EC

Supplementary Information:

- The product is assigned a regulatory model designation which denotes the regulatory aspects of the design. The regulatory model designation is the main product identifier in the regulatory documentation and test reports, and is marked on the product's dataplate label. The regulatory model designation should not be confused with the product name(s) for marketing purposes.
- The product is a component for use with Kodak's Imaging Devices.
- The product is rated 200-240 V AC, 50/60 Hz, 12 A, cord connected, Class I.
- The product is high-powered (>1 kW) for professional use and is therefore exempt from the requirements of EN 61000-3-2.
- Kodak Graphic Communications Canada Company is registered to ISO 9001.

European Contact: Israel Sandler, Managing Director, Creo EMEA S.A., a subsidiary of Kodak, Waterloo Office Park, Building E-F, Drève Richelle 161, B-1410 Waterloo, Belgium, Phone +32.2.352 25 11, Fax +32.2.351 09 15.

Burnaby, 10 November 2006

Keith Poulin
Product Safety & Compliance

Kodak Graphic Communications Canada Company
3700 Gilmore Way • Burnaby • BC • Canada • V5G 4M1
Phone 604.451.2700 • Fax 604.437.9891

Figure 37: EC Declaration of Conformity for the debris removal unit

Compliance With Standards for Laser Safety

The Magnus XLF 80 output device has been designed, tested, and evaluated for compliance with the following laser safety standards:

- U.S. Federal Regulations 21 CFR 1040.10, in accordance with the regulations of the Center for Devices and Radiological Health (CDRH) of the U.S. Food and Drug Administration
- EN 60825-1, *Safety of Laser Products*

The Class 1 Laser Product label on the output device indicates compliance with these standards. For an example of this label, see page 14.



WARNING: Use of controls or adjustments or performance of procedures other than those specified in the help system or visual reference guide may result in hazardous radiation exposure.

Compliance With Standards for Electromagnetic Interference and Electromagnetic Compatibility

Electromagnetic Interference (EMI)

The Magnus XLF 80 output device has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the output device is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with this guide, may cause harmful interference to radio communications. Operation of the output device in a residential area is likely to cause harmful interference. You must correct the interference at your own expense.

The FCC compliance statement label on the output device indicates compliance with these limits. For an example of this label, see page 14.

Electromagnetic Compatibility (EMC)

The Magnus XLF 80 output device has been designed, tested, and evaluated for compliance with the EMC Directive 89/336/EEC. It complies with the following EMC standards:

- EN 55011, Class A
- EN 61000-3-3
- EN 61000-6-1

Compliance With Standards for Noise Emissions

The Magnus XLF 80 output device has been designed, tested, and evaluated for compliance with the maximum noise emission limit permitted for a light industrial environment, 80 dB(A). Noise emissions from the Magnus XLF 80 output device will not exceed 76 dB(A) when tested in accordance with EN ISO 7779:2001, *Acoustics — Measurement of airborne noise emitted by information technology and telecommunications equipment*.

Index

B

beware of moving parts when interlock deliberately overridden label, 19

C

caution safety messages, about, 3
CDRH compliance statement label, 14, 34
CE mark, 13, 24, 32
Center for Devices and Radiological Health, 34
clamps, hazards related to
  damage to drum, 6
  pacemaker interference, 6
  pinched fingers, 6
Class 1 laser product label, 14, 35
Class 4 laser product label, 22, 23, 30
cleaning solutions, 6
compliance. *See* Regulatory Compliance
compressed air, hazards related to, 6, 20
CSA 60950-1, 32
CSA International mark, 13, 21, 22, 32
CSA mark, 24
C-Tick, 13
C-Tick mark, 24

D

danger safety messages, about, 3
dataplate label, 13, 32
date of manufacture, 13, 21, 22
Declaration of Conformity. *See* EC Declaration of Conformity
Directive of Machinery 98/37/EC, 32

E

EC Declaration of Conformity, 33, 34
electrical rating, 13
electrical safety
  fuse replacement label, 17
  hazardous voltage label, 5, 16
  high touch current label, 16
  service key switch, 4, 19
  shock hazard from liquids, 5
  standards, 32
  turn off electrical power, 9
  unauthorized panel removal, repairs, changes, 4
EMC Directive 89/336/EEC, 32, 35
emergency stop
  button, 10
  switch, 9
EMI/EMC compliance, 35
emissions, 5
EN 55022, Class A, 35
EN 55024, 35
EN 60204-1, 32
EN 60825-1, 34
EN 60950-1, 32
EN 61000-3-3, 35
environmental specifications, 35
exposure head aperture label, 22, 30

F

fan box, 16
FCC compliance statement label, 14, 35
filters, 3, 6
fire, 6
fuse replacement label, 16

G

gaseous emissions, 5
gloves, protective, 6

H

hazardous voltage label, 5, 16
high touch current label, 16

I

Identification label, 24
identification labels, 13
Information Technology Equipment, 32
installation, safety guidelines, 2
interlock system, 4, 8

K

keep hands out label, 18

L

labels
  beware of moving parts when interlock deliberately overridden, 19
  CDRH compliance statement, 14
  CE mark, 13, 24, 32
  Class 1 laser product, 14, 35
  Class 4 laser product, 23, 30
  CSA International mark, 13, 21, 22, 32
  CSA mark, 24
  C-Tick mark, 24
  dataplate, 13, 32
  exposure head aperture, 22, 30
  FCC compliance statement, 14
  fuse replacement, 16
  hazardous voltage, 5, 16
  high touch current, 16
  Identification, 24
  identification, 13
  keep hands out, 18
  laser hazard, 23
  laser interlocked panel, 15
  laser noninterlocked panel, 15
  maximum PSI/BAR, 20
  pacemaker warning, 21
  Particulate Airborne Emissions, 24
  radiation output, 22, 30
  regulatory complicance, 13
  safety interlock override, 19
  solenoid lock, 18
  UDRC-BP Configuration, 24
laser hazard label, 23
laser interlocked panel label, 15
laser noninterlocked panel label, 15
laser safety
  Class 4 laser product label, 23, 30
  emergency stop button, 10
  exposure head aperture label, 22, 30
  interlock system, 7
  labels on access panels, 15
  labels on exposure head, 21
  laser hazard label, 23
  laser interlocked panel label, 15
  laser noninterlocked panel danger label, 15
  panel removal, 4, 8
  radiation output label, 22, 30
  service access only, 4
  standards, 34
  unauthorized repairs, 4
liquids, hazards related to, 5
Low Voltage Directive 73/23/EEC, 32

M

magnetic clamps, hazards related to
  damage to drum, 6
  pacemaker interference, 6
  pinched fingers, 6
maintenance, safety guidelines, 3
manufacture date, 13, 21, 22
Material Safety Data Sheet, 5
maximum PSI/BAR label, 20
mechanical safety
  beware of moving parts when interlock deliberately overridden label, 19
  keep hands out label, 18
  laser interlocked panel label, 15
  laser noninterlocked panel danger label, 15
  removing panels, 4, 5, 8

repairs needed, 8
standards, 32
media, hazards related to
gaseous emissions from unqualified media, 5
sharp plate edges, 6
messages, safety, 3
MSDS, 5

N

noise emissions, 35
notice messages, about, 3

O

operation, safety guidelines, 3

P

pacemaker warning, 6, 21
panels
interlock defeated, 15
interlock system, 7
noninterlocked, 15
removal, 4, 8
service access only, 4, 15
Particulate Airborne Emissions label, 24
plates, hazards related to
gaseous emissions from unqualified media, 5
sharp plate edges, 6
power box, 19
power switch, 6, 8, 9
PSI/BAR, maximum, 20

R

radiation output label, 22, 30
regulatory approval model, 32
regulatory compliance
electrical safety, 32
EMI/EMC, 35
labels, 13
laser safety, 34
mechanical safety, 32
noise emissions, 35
repairs, 4

S

safety
electrical, 32
laser, 34
mechanical, 32
safety features, 7
safety interlock override label, 19
safety messages, about, 3
Safety of Laser Products, 34
Safety of Machinery, 32
serial number, 13, 21, 22
service access only, 2, 4, 19, 20
service key switch, 4, 19
slip sheets, hazards related to, 6
solenoid lock label, 18

T

thermal exposure heads, labels, 21
TSM, 32

U

UL 60950-1, 32

V

voltage, hazardous, 5, 16

W

warning safety messages, about, 3
water, hazards related to, 5