Plate Alignment Label Placement

Context Trendsetter Autoloader

Background This procedure is a fundamental part of any Autoloader install.

Tools and parts Alignment labels.

If you have no alignment labels, a Plate Alignment Labels pdf file is available on the Intranet. Print this file onto a sheet of sticky-back material. (See http://intranet.creo.com/support/html/output/trendsetter_al/nav/install.htm)

Steps Pace the labels with respect to the center line of the load ramp. (The center line runs through the plate sensor in the middle of the load ramp.)

All distances are in mm. For a broadsheet of width W:
If W > 559, place a label W/2 to the right of the center line.
If W <=559, place a label W/2 + 117 to the right of the center line.