Servicing the Flash Cover Cable System

Context

☑ ThermoFlex

Background

The flash cover motion is straight and does not bind due to an internal cable system.

Tools and parts

- 2.5mm, 3mm, 5mm Allen key
- BrecoFlex frequency meter

Steps

1. Remove the flash cover (see flash cover removal procedure).
2. Inspect the cable and pulleys for damage.

   The cable should be taught but not excessively tight. Movement of the cables and pulleys should require minor effort.
3. If parts require replacement, proceed to the next step.
4. Remove the cable ties from the turnbuckle and untension the cable.
5. Check the pulleys and replace damaged or worn parts.
6. Re-assembly is the reverse of removal. Tension the cable to 30Hz and install new cable ties to prevent the turnbuckle from rotating.
7. Re-install the flash cover.