Flash cover Removal and Installation

Context

☑ ThermoFlex

Background

The flash cover must be removed to gain access to the lock/detent mechanism and position sensors. Two people are needed to remove the flash cover.

Tools and parts

- 3mm, 4mm Allen Keys

Steps

Removal:

1. Remove the two cover plates.
2. Slide the flash cover away from the drum as far as possible to expose the cable anchor brackets.
3. Remove the fasteners from the anchor points.
4. The flash cover is now free to be removed from the machine. Removal and handling of the flash cover is a two person operation particularly if space is limited. Slide the flash cover away from the drum until is it free of the roller mechanism.
5. Check the condition of the detent bar, detent plunger, rollers, and switches.

Installation:

1. Installation is the reverse of removal.
2. Ensure both cable anchor brackets are bottomed against the cable pulleys.
3. Slide the flash cover straight onto the roller mechanism.
4. Prior to attaching the cable anchors, the flash cover is easy to skew and bind.

Notes

Type f**lashcvr unlock** to retract the lock cylinder allowing the flash cover to slide freely.