Replacing a Vacuum Generator

Applies to	ThermoFlex
Background	Vacuum generators provide suction at the table surface to hold down the media in order to allow the cover sheet to be pulled off, and also to provide drag on the film during loading.
Tools and parts	¾" open end wrench
Steps	1. Remove the air tubes from the inlet and outlet of the vacuum generator 2. Remove the nut from the bulkhead fitting 3. Pull the vacuum generator out of the bracket 4. Remove the bulkhead fitting from the vacuum generator 5. Screw the bulkhead fitting onto the new vacuum generator using teflon tape on the threads 6. Put the vacuum generator back into the bracket 7. Tighten the nut on the bulkhead fitting 8. Re-install the air tubes
Notes	
Technical contact	Michael Herbert (mherbert@creo.com)
Date submitted	November 01, 1999
Date modified	November 04, 1999