Removing the rear panel of the Trendsetter 3230 (TS4 Version)

Background

The rear panel of the base Trendsetter 3230 (TS4 Version) is fastened to the chassis from the interior. The rear panel of the autoloader version is fastened to the chassis from the exterior.

Context

☑ Trendsetter 3230 (TS4 Version)

Special tools

- 5 mm hex key

Steps

Base Trendsetter

1. Lift the front panel to its fully open position. This action unlocks the top panel.
2. Lift the top panel to its upright position to expose the interior of the Trendsetter.

Caution: before removing screws, ensure that the rear panel does not fall away from the chassis and become damaged.

3. Using the hex key, loosen and remove the screws that fasten the rear panel to the chassis. These screws are located on the left and right flanges of the rear portion of the chassis.
4. Gently lift the rear panel off and away from the locating pins at the base of the chassis.
5. To replace panel, follow the above steps in reverse.

Trendsetter Autoloader

1. Lift the autoloader unload table using the pneumatic controls on the autoloader. If the compressed air is not connected, manually lift the autoloader unload table and pin it in a raised position by inserting a large bolt or hex key through one of the holes in the pivot bracket and the matching hole in the unload table.
2. Using the hex key, loosen and remove the screws that fasten the rear panel to the chassis. These screws are located on the angle brackets to the left and right of the autoloader unload table at the rear of the Trendsetter.
3. Gently lift the rear panel off and away from the locating pins at the base of the chassis.
4. To replace panel, follow the above steps in reverse.

Caution: Remove any objects used to pin the autoloader unload table to the raised position before proceeding with other activities.