

Thermal 3 Exposure Head

Firmware Version 1.03.07 Release Notes

Document Number
719-00711A-A

27 Jun 2006

Copyright 2006 Kodak. All rights reserved.

Revision History

Revision	Date	Author	Comments
A	27 Jun 2006	Rick Sherlock	Created for TH3 firmware V1.03.07

Thermal 3 Exposure Head
Firmware Version 1.03.07 Release Notes

CONTENTS

Revision History i

1. Getting Started 1

2. Laser Safety Practices 1

3. Related Resources 1

4. Problems Fixed 1
   4.1 Fixed a sporadic error turning the write laser off 2

1. GETTING STARTED

For full details on how to install the firmware, see "Thermal 3 Firmware Installation Procedure".

Note: This document does not provide specific information about any host platform.

Formatting conventions used in this document:

- All references to monitor commands are in `courier font`. Monitor commands for the exposure head are preceded by the `TH2 >` prompt and monitor commands for the host are preceded by the >> prompt.
- All references to NVS parameters are in *italics*.
- All references to scripts are **bold**.

2. LASER SAFETY PRACTICES

To use this document, you *must* have attended an exposure head introductory course given by the Kodak service training department, product specialist, or engineering support team. You must be familiar with the necessary safety precautions when working with a thermal head.

DANGER: *Never operate the host device with the write laser beam on and a door open. Do not use the service bypass jigs to bypass the door interlocks.*

3. RELATED RESOURCES

- Thermal 3 Firmware Installation Procedure: **TechPlanet** > **Output** > **Heads** > **Thermal 3 Head > Installation** (http://techplanet.creo.com/output/heads/thermal_3/nav/install.htm)
- Thermal 3 exposure head firmware: **TechPlanet** > **Output** > **Heads** > **Thermal 2 Head > Control/settings > Firmware releases** (http://techplanet.creo.com/firmware/CTP/Head/Thermal3/versions.htm)
- Thermal 3 exposure head controls and settings: **TechPlanet** > **Output** > **Heads** > **Thermal 3 Head > Control/settings** (http://techplanet.creo.com/output/heads/thermal_3/nav/control-set.htm)
- Service Shell: **TechPlanet** > **Output** > **Service Tools** > **Service Shell** (http://techplanet.creo.com/output/service_tools/service_shell/nav/v2-x/index.htm)
- Controlled Releases: **TechPlanet** > **Output** > **All CTP Devices** > **Control/settings** (http://techplanet.creo.com/output/computer_to_plate/all_ctp/nav/control-set.htm)

4. PROBLEMS FIXED

This section lists problems that have been fixed in thermal 3 firmware version 1.03.07.

4.1 Fixed a sporadic error turning the write laser off

All exposure heads and hosts have been developed with the expectation that turning the write laser off doesn't require a significant amount of time. In an attempt to improve the laser lifetime, Thermal 3 turns the write laser off by ramping down the write laser current. As a result, turning the write laser off for Thermal 3 can require seconds.

Very sporadically, the delay exceeds five seconds, which causes an error turning the write laser off. To fix the problem, an internal timeout was increased from five seconds to twenty seconds to ensure that there is sufficient time to ramp down the write laser current.