Common Status Checks

MPE	MCE	Notes
	safety	safety loop status
	drum	drum status
	flyoff	flyoff status
	engine	status of media handling subsystem
	door	Shows the status of the door loop
	flush	Flush all jobs and reinitialize the device. An easy way to reinitialize the device.
	status	Show status of various parts of the system - head, drum, carriage, etc.
ale init	init	Similar to flush but doesn't kick off a plate on the drum
list modules	list version all	list all internal firmware module versions
list media	media	display all configured media
list stats	image stats	display various statistics (number of plates, errors, etc.)
list version	list version	list product version and board versions
mask door creo	n/a	Not required with the new safety loop.
nvs dump	prm all	displays all nvs parameters
nvs dump diff	prm diff	display all parameters different from default values
n/a	verbose	Verbose reporting commands.