FCO #512-00215A Update 5 for Xpose version 1.1.47

Document number: 719-00386A-EN Rev A

Release date: 23 Dec 2004

Applies to

- Lotem® 400 Xpose
- Lotem 200K

Priority: Next failure

Machines affected N/A

Component N/A

Problem

- With TIFF files generated from a Prinergy job, between jobs, the platesetter does not start to load the next plate until the previous plate is unloaded. This causes low throughput.
- When you increased the default of the machine Timeout parameter, the new value was not saved. The default value has been increased to 25 minutes, and you can increase this value and save the new value successfully.
- In the Excurve dialog box, processless plates did not appear in the media list.
- Jobs from a remote station with a layout rotation of 90° or 270° crashed during expose.
- After a rotated job aborted, the next job sent to the queue appeared twice.

Solution

Install update 5: Update 5 enables a flow that sends all of the separations of a layout in one job.

For more information, see the update 5 release notes on the Reference page in TechPlanet.

Time required 1 hour

Prerequisite FCOs 512-00097A (Lotem Controller 1.60.09)

Parts included in FCO

Part Number	Part Name	Quantity
651-00214A	Lotem Xpose version 1.1.47 + update 5 CD master	1
719-00386A	FCO document	1

FRU after FCO implementation 651-00214A

Tools required N/A

FCO #512-00215A

Procedure

Installation notes

- Update 5 includes Update 3.
- Update 5 is available on CD only.
- Install Update 5 after installing version 1.01.047.
- Update 5 can be un-installed, if required. (See release notes on the Reference page in TechPlanet.)

To install the update

IMPORTANT: Before you install Update 5, verify that LotemXpose 1.01.047 is already installed.

1. Verify that Lotem Xpose Update 3 is not installed. Uninstall Update 3, if required. (Use the uninstall file, and restart the workstation before and after uninstalling Update 3.)
2. On the Lotem workstation, close all applications and windows.
3. Insert the Lotem Xpose CD and browse to LotemXpose_Extra\LotemXpose_Upd5.
4. Save update 5 on your PC.
5. Browse to the folder in which you saved Update 5 and double-click LotemXposeUpd_5.EXE to open the update installation wizard.
6. Follow the instructions in the wizard. When the wizard installation is complete, the workstation restarts.
7. Restart the Lotem workstation.

Note: You must always restart the workstation after each software and update installation.

Important: After installing the update, to update the registry, in TechPlanet, browse to the FCO page and download with the FCO tracker file according to the instructions in the link on the FCO page.

To check that the update has been installed

In the Lotem Xpose application, from the Help menu, select **About**. In About LotemXpose, the version should be **1.01.047 Upd 005**.

Upon completion N/A

Logistics Approved quantities:

CSC	Quantity
CAM	30
CEU	20
CAP	10
CJP	5
CMA	5

FCO #512-00215A

Material disposition	N/A
See also	Release notes on the Reference page in TechPlanet
Technical contact	Mario Amir
Date submitted	23 Dec 2004
Last updated	23 Dec 2004