ThermoFlex Wide

Installation of UDRC-BP with External Venting

Document Number
719-00377A-A

2004-09-30

Creo Inc.
3700 Gilmore Way
Burnaby, BC
Canada V5G 4M1
(604) 451-2700

Copyright 2004 Creo Inc. All rights reserved.

Revision History

Revision	Date	Author	Comments
A	30 Sept 2004	ADobric	First Release

creo

ThermoFlex Wide
Installation of UDRC-BP with External Venting

CONTENTS

Revision History i

1. Tools Needed 2

2. Parts Needed 2

3. Procedure 2
   3.1 Connect the blower exhaust to the external interface 2

1. TOOLS NEEDED

- small flathead screwdriver

2. PARTS NEEDED

- UDRC-BP with External Venting 500-01955A or 500-01956A

3. PROCEDURE

3.1 Connect the blower exhaust to the external interface

1. Ensure that the UDRC Site Preparation Guide 725-00089A has been followed for preparing for external venting before continuing installation.
2. Connect the UDRC to the output device as recommended in the UDRC Installation Procedure 750-00091A.
3. Attach the 1½ in. hose 56-3467 to the bulkhead, and the free end of the hose to the customer-supplied interface.

Note: The UDRC must be located within 1.0 m (40 in.) of the hard-piped interface. It must not be left on its casters - place it on the adjustable height leveling feet.

4. Ensure the complete filter assembly is in the UDRC.
   - the particulate filter spacer at the bottom of the pot, and
   - the 16” particulate filter
5. Update the UDRC firmware parameters for the external venting option. See the media tech notes on TechPlanet - the media list is at http://techplanet.creo.com/consumables/media/nav/medialist.htm

   For example, on ThermoFlex Wide II:
   Activate the UDRC base mode of operation:

```
Flexo>> access enable
Flexo>> option debris udrcl disable
Flexo>> option debris udrcb enable
Flexo>> reset
```

   Ensure all media are set up to the UDRC-B operation:

```
Flexo>> set media <n> debrisoptions 3
```