QUICK REFERENCE TH2 COMMANDS FOR NEWS

For commands that are used by the head only, you must always type the following:

```
redirect enable
eng
```

Once the command is complete, type:

```
redirect disable
```

Thermal 2 Commands

This Th 2 Command	Produces This Information
`foc cal reflect`	surface reflectivity
`volt`	voltage and humidity
`temp`	temperature
`ver`	firmware version
`set sys`	head resolution and serial number
`ldd info`	current
`lvd info`	offset and swath width
`bbs info`	shutter close or open
`sts info`	statistics info
`set ldd`	nominal current
`set bbs`	maximum error

For more detailed information, refer to the Thermal 2 Document Th1.x vs Th2: Monitor Commands and NVS Parameters.