Customer
Installation Guide

English

Brisque version 4.1 Additional Updates

653-00514A

www.creo.com

Copyright

Copyright © 2003 Creo Inc. All rights reserved.

No copying, distribution, publication, modification, or incorporation of this document, in whole or part, is permitted without the express written permission of Creo. In the event of any permitted copying, distribution, publication, modification, or incorporation of this document, no changes in or deletion of author attribution, trademark legend, or copyright notice shall be made.

No part of this document may be reproduced, stored in a retrieval system, published, used for commercial exploitation, or transmitted, in any form by any means, electronic, mechanical, photocopying, recording, or otherwise, without the express written permission of Creo Inc.

This document is also distributed in Adobe Systems Incorporated's PDF (Portable Document Format). You may reproduce the document from the PDF file for internal use. Copies produced from the PDF file must be reproduced in whole.

Trademarks

The Creo wordmark, Creo logo, and the names of the Creo products and services referred to in this document are trademarks of Creo Inc.

Adobe, Acrobat, and the Acrobat logo are registered trademarks of Adobe Systems Incorporated, and are registered in the U.S. Patents and Trademark Office and may be registered in other jurisdictions.

Apple, AppleTalk, AppleShare, EtherTalk, LocalTalk, Macintosh, and LaserWriter are trademarks of Apple Computer, Inc.

Microsoft, Windows, Windows 2000, and Windows NT are trademarks or registered trademarks of Microsoft Corp.

Xerox is a registered trademark of Xerox Corp.

Other brand or product names are the trademarks or registered trademarks of their respective owners.

FCC Compliance

The Creo equipment referred to in this document complies with the requirements in Part 15 of FCC Rules for a Class A computing device. Operation of the Creo equipment in a residential area may cause unacceptable interference to radio and TV reception, requiring the operator to take whatever steps are necessary to correct the interference.

Limitation of Liability

The product, software or services are being provided on an "as is" and "as available" basis. Except as may be stated specifically in your contract, Creo Inc. expressly disclaims all warranties of any kind, whether express or implied, including, but not limited to, any implied warranties of merchantability, fitness for a particular purpose and non-infringement.

You understand and agree that Creo Inc. shall not be liable for any direct, indirect, incidental, special, consequential or exemplary damages, including but not limited to, damages for loss of profits, goodwill, use, data or other intangible losses (even if Creo has been advised of the possibility of such damages), resulting from: (i) the use or the inability to use the product or software; (ii) the cost of procurement of substitute goods and services resulting from any products, goods, data, software, information or services purchased; (iii) unauthorized access to or alteration of your products, software or data; (iv) statements or conduct of any third party; (v) any other matter relating to the product, software, or services.

The text and drawings herein are for illustration and reference only. The specifications on which they are based are subject to change. Creo Inc. may, at any time and without notice, make changes to this document. Creo Inc., for itself and on behalf of its subsidiaries, assumes no liability for technical or editorial errors or omissions made herein, and shall not be liable for incidental, consequential, indirect, or special damages, including, without limitation, loss of use, loss or alteration of data, delays, or lost profits or savings arising from the use of this document.

Patents

This product is covered by one or more of the following U.S. patents:

RE37,376	5,325,217	5,532,728	5,742,743	5,996,499	6,158,345	6,353,216
4,558,302	5,339,176	5,561,691	5,764,374	5,998,067	6,159,659	6,366,339
4,743,091	5,343,059	5,568,595	5,764,381	6,003,442	6,164,637	6,371,026
4,992,864	5,355,446	5,576,754	5,771,794	6,014,471	6,180,325	6,377,739
5,049,901	5,359,451	5,579,115	5,785,309	6,016,752	6,181,362	6,387,597
5,079,721	5,359,458	5,592,309	5,813,346	6,031,932	6,181,439	6,396,422
5,103,407	5,367,360	5,594,556	5,818,498	6,043,865	6,186,068	6,396,618
5,111,308	5,384,648	5,600,448	5,854,883	6,060,208	6,189,452	6,407,849
5,113,249	5,384,899	5,608,822	5,861,904	6,063,528	6,191,882	6,414,755
5,122,871	5,412,491	5,615,282	5,861,992	6,063,546	6,204,874	6,422,801
5,124,547	5,412,737	5,625,766	5,875,288	6,072,518	6,208,369	6,435,091
5,132,723	5,420,702	5,636,330	5,894,342	6,090,529	6,214,276	6,441,914
5,150,225	5,420,722	5,649,220	5,900,981	6,096,461	6,217,965	6,450,092
5,153,769	5,459,505	5,650,076	5,934,196	6,098,544	6,260,482	6,456,396
5,155,782	5,473,733	5,652,804	5,942,137	6,107,011	6,266,080	6,476,931
5,157,516	5,481,379	5,680,129	5,946,426	6,112,663	6,266,134	6,477,955
5,208,818	5,488,906	5,691,823	5,947,028	6,115,056	6,267,054	6,509,903
5,208,888	5,497,252	5,691,828	5,958,647	6,121,996	6,268,948	
5,247,174	5,508,828	5,696,393	5,966,504	6,130,702	6,283,589	
5,249,067	5,509,561	5,699,174	5,969,872	6,134,393	6,295,076	
5,283,140	5,517,359	5,699,740	5,973,801	6,136,509	6,299,572	
5,291,273	5,519,852	5,708,736	5,986,819	6,137,580	6,318,266	
5,323,248	5,526,143	5,713,287	5,995,475	6,147,789	6,352,816	

Creo Inc.
3700 Gilmore Way
Burnaby, B.C., Canada
V5G 4M1
Tel: 1-604-451-2700
Fax: 1-604-437-9891

http://www.creo.com

653-00514A

Revised May 2003

Brisque version 4.1 Additional Updates

Read Me First 2
Brisque version 4.1 Additional Updates 2
Loading the Additional Updates 3
DTManager Workflow and Updates 4
Installing the DTManager Updates 5
Checking the Software Version Installed on the RiproServer/Timna v3.x 6

Read Me First

The Additional Updates CD comes to address certain Brisque configurations and to provide you with a solution that helps manage Brisque and Server stations running on different versions of Brisque.

The updates that are included in the CD configure specific definitions that relate to the PackJob, TIFF/IT, and Improof workflows.

The Additional Updates CD contains the following:

- Updates for Brisque version 4.1
- DTManager workflow and updates

Brisque version 4.1 Additional Updates

Update 1) **PackJob Update** (Upd_Brisque41_PackJob)

Symptom:

Lines may appear in separations and run through elements.

Who should install the update?

- Customers who expose PackJobs created using LRS, StepOne, or any other PCF workflow.
- Customers who output plates to TrendSetter or Screen2Go of any Jobs, including CTs with different resolution.

Update 2) TIFF/IT Update (Upd_Brisque41_TIFFIT-FP)

Symptom:

When translating a Job to TIFF/IT, the FP preview info is corrupted.

Who should install the update?

Customers who translate Jobs to TIFF/IT.

Update 3) Improof Update (Upd_Brisque41_Improof)

Symptom:

Intermittent problems with HP Improofers. First few Jobs would print correctly but then would fail with a "Proofer Communication Error".

Who should install the update?

Customers who use Improof, mainly on HP models.

For the latest information visit: https://eCentral.creo.com/

Loading the Additional Updates



Note: These instructions apply to all the updates.

To load the additional Updates:

1. Insert the **Brisque V4.1 Additional Updates CD (#7)** into the CD-ROM drive.
2. From the Launch Pad, open the Services menu and double-click the **LoadUpdate** icon.
3. In the login dialog, type `root`, type your password (`ripro`), and then press ENTER.

   The LoadUpdate application is started.
4. Select the **Install** tab.
5. Select the **CD** button.

   All the updates are listed.
6. Choose the desired updates from the list, and click **Install**.
7. Click **OK** (to reboot).

   Brisque reboots before and after the update is loaded.
8. Remove the **Brisque V4.1 Additional Updates CD (#7)** from the CD-ROM drive.
9. After rebooting, login as `cdesci` and go to **Station Info>More Info** to confirm the installation.

DTManager Workflow and Updates

Overview

Brisque and Brisque Serve stations use Helios software to support network communication between any station and the Macintosh. Helios software provides Macintosh computers with access to files and folders on mounted Brisque or Server stations.

Depending on the origin of the file, Helios and Brisque tag each file with a unique ID. On rare occasions, and when very specific circumstances occur, the IDs created may be incorrect and therefore interfere with the identification of the file. In these cases the files may be inaccessible.

Brisque version 4.1 includes a DTManager application that provides a reliable solution for such cases.

Creo strongly recommends that all Brisque stations on the same network are upgraded to version 4.1.

If it is not possible to upgrade all Brisque stations to version 4.1, and in order to ensure file integrity, all Brisque and Brisque Serve stations (including RiproServer/Timna) should have the DTManager application installed.



Note: For more information and installation assistance, please contact your local Creo support.

Installing the DTManager Updates



Note: Reinstall the DTManager update after every cold start or software installation.

Note: DO NOT install any previous 'rsrc' update on top of the new DTManager update.

Loading the DTM update on Brisque v4.0.97.xx

1. Insert the **Brisque V4.1 Additional Updates CD (#7)** into the CD-ROM drive.
2. Logout from the Brisque and reboot.
3. Login as `root`, and type your password (`ripro`).
4. At the command prompt, type `scismit` and press ENTER to access the SciSmit main menu.
5. From the SciSmit main menu, select **Software Handling**, and then select **Update Software Packages**.
6. Press F4 to display the list of updates.
7. Select **Upd_Brisque4_97_DTM**, and press ENTER twice.

   Upon completion, the Brisque system automatically reboots.
8. Remove the **Brisque V4.1 Additional Updates CD (#7)** from the CD-ROM drive.
9. After rebooting, login as `cdesci` and go to **Station Info>More Info** to confirm the installation of **Upd_Brisque4_97_DTM.obj** 4.0.97.2.

Loading the DTM update on Brisque v3.0.38.xx

1. Insert the **Brisque V4.1 Additional Updates CD (#7)** into the CD-ROM drive.
2. Logout from the Brisque and reboot.
3. Login as `root` and type your password (`ripro`).
4. Type `UpdInstall Upd_Brisque3_DTM` and press ENTER.

   Upon completion, the Brisque system automatically reboots.
5. Remove the **Brisque V4.1 Additional Updates CD (#7)** from the CD-ROM drive.

6. After rebooting, login as `cdesci` and go to **Station Info>More Info** to confirm the installation of **Upd_Brisque3_DTM.obj** 1.2.0.0.

Loading the DTM update on Brisque Serve v4.0.x

1. Insert the **Brisque V4.1 Additional Updates CD (#7)** into the CD-ROM drive.
2. Logout from the Brisque and reboot.
3. Login as `root` and type your password (`ripro`).
4. At the command prompt, type `scismit` and press ENTER to access the SciSmit main menu.
5. From the SciSmit main menu, select **Software Handling**, and then select **Update Software Packages**.
6. Press F4 to display the list of updates.
7. Select **Upd_BS_DTM**, and press ENTER twice.

   Upon completion, the Brisque automatically reboots.
8. Remove the **Brisque V4.1 Additional Updates CD (#7)** from the CD-ROM drive.
9. After rebooting, login as `cdesci` and go to **Station Info>More Info** to confirm the installation of **Upd_BS_DTM.obj** 4.0.20.1.

Checking the Software Version Installed on the RiproServer/Timna v3.x

To verify that the correct version is installed:

1. Logout from the application and reboot.
2. Login as `root` and type your password (`ripro`).
3. Type `Scismit` and press ENTER.
4. From the Scismit menu, select **Information**, then select **Display Software Versions**.
5. Press F4 to display the list of updates.
6. Select **Upd*** from the list, and press ENTER twice.

7. Verify that the correct update is listed.
   For example, if you installed the DTManager update on RiproServer/Timna v3.1.7.0 + UpdTimna 3.1.7.8, then **UpdTimn_3.1.Base.obj 3.1.7.8** should appear in the list.
8. Press F10 to exit Scismit.

Loading the DTM update on RiproServer/Timna v3.1.7.0 + UpdTimna 3.1.8.7



Important: Before loading the DTManager, verify that the following versions are installed on the system:

- Timna version 3.1.7.0
- UpdTimna_3.1.Base_3.1.8.7



Note: To check and see what version you have installed on your system, refer to *Checking the Software Version Installed on the RiproServer/Timna v3.x* on page 6.

1. Insert the **Brisque V4.1 Additional Updates CD (#7)** into the CD-ROM drive.
2. Logout from the application and reboot.
3. Login as `root` and type your password (`ripro`).
4. Type `smit install_latest` and press ENTER.
5. Press F4, select **CD0**, and then press ENTER.
6. Press F4 to display the list of updates.
7. Scroll down and select **Upd_Timna_DTM**, and then press ENTER twice.
8. At the `ARE YOU SURE?` prompt, press ENTER.
9. Upon completion, press F10.



Note: If the loading of the DTManager update has failed, scroll down and look for the update information that is displayed at the bottom of the message and repeat the procedure with the correct DTManager update.

10. Remove the **Brisque V4.1 Additional Updates CD (#7)** from the CD-ROM drive.
11. Type `lslpp -l | grep Upd` to confirm that **Upd_Timna_DTM.obj** 3.1.0.2 is listed.
12. Type `exit` to go back to the login prompt, and then login as `cdesci`.

Loading the DTM Update on RiproServer/Timna v3.1.7.0 + UpdTimna 3.1.7.8



Important: Before loading the DTManager, verify that the following versions are installed on the system:

- Timna version 3.1.7.0
- UpdTimna_3.1.Base_3.1.7.8



Note: To check and see what version you have installed on your system, refer to *Checking the Software Version Installed on the RiproServer/Timna v3.x* on page 6.

1. Insert the **Brisque V4.1 Additional Updates CD (#7)** into the CD-ROM drive.
2. Logout from the application and reboot.
3. Login as `root` and type your password (`ripro`).
4. Type `smit install_latest` and press ENTER.
5. Press F4, select **CD0**, and then press ENTER.
6. Press F4 to display the list of updates.
7. Scroll down and select **Upd_Timna_3178_DTM**, and then press ENTER twice.
8. At the `ARE YOU SURE?` prompt, press ENTER.
9. Upon completion, press F10.



Note: If the loading of the DTManager update has failed, scroll down and look for the update information that is displayed at the bottom of the message and repeat the procedure with the correct DTManager update.

10. Remove the **Brisque V4.1 Additional Updates CD (#7)** from the CD-ROM drive.
11. Type `lslpp -l | grep Upd` to confirm that **Upd_Timna_3178_DTM** 3.1.7.1 is listed.
12. Type `exit` to go back to the login prompt, and then login as `cdesci`.