EP Release Notes

English

Brisque

version **4.0.5.15**

653-00010A

www.creo.com

Copyright ©2002 by Creo Inc. All Rights Reserved. Data subject to change without notice.

Creo and the Creo logo are trademarks or registered trademarks of Creo Inc. The Creo products mentioned in this document are trademarks or service marks of Creo Inc. and may be registered in certain jurisdictions.

Apple, AppleTalk, AppleShare, EtherTalk, LocalTalk, Macintosh, and LaserWriter are trademarks of Apple Computer, Inc., registered in the USA and other countries. Adobe and PostScript are trademarks of Adobe Systems Inc., are registered in the US Patent and Trademark Office, and may be registered in other jurisdictions as well. Acrobat, the Acrobat logo, PDF, Adobe Illustrator, and Adobe Font Downloader, are trademarks of Adobe Systems Inc., which may be registered in certain jurisdictions. Other company and brand, product and service names are for identification purposes only and may be trademarks or registered trademarks of their respective holders.

Brisque version 4.0.5.15 EP Release Notes

Overview 2
Logistics 2
Documentation and Training 4
Prerequisites 4
Known Bugs and Limitations 5
Before Loading the Software 5
Loading Instructions 6

Overview

Brisque software update 4.05.15 is ready for early production.

This update supports Creo Trendsetter Quantum V- Speed devices directly connected to Brisque performance (6F1) stations.

Connectivity to Trendsetters is performed via an appropriate DCK (2xTSP boards).

Update 4.05.15 should be installed on top of Brisque version 4.0.97 (EP) or later.

Supported devices:

Trendsetter 400 Quantum V

Trendsetter 800 Quantum V

Trendsetter VLF Quantum 4557 V, 5067 V, 5467 V, 5080 V, 5880 V

Logistics

Device connectivity kits

501R49728 - Brisque to TS 400 Quantum V Direct DCK

501R49714 - Brisque to TS 800 Quantum V Direct DCK

501R49715 - Brisque to TS VLF Quantum V Direct DCK

501R49948 - Brisque to TS 400/800 Quantum V DCK for Performance Dual and F50

The **Brisque Update 4.05 for TS V** software kit (510V3R796) is included in each one of the above DCKs.

DCK kits Contents

- **501R49728 Brisque to TS 400 Quantum V DCK**

  S/W CD, PRINTCONSOLE 2.1

  BRISQ2TS FOR DIRECT CONNECTIVITY

  License Brisque Staccato 20

  Adobe (add) royalties for CTP (4Up)

- **501R49714 Brisque to TS 800 Quantum V DCK**

  S/W CD, PRINTCONSOLE 2.1

  BRISQ2TS FOR DIRECT CONNECTIVITY

  KIT, ROTATION 2 BOARD 128MB

  TSP BOARD ONLY

  License Brisque Staccato 20

  Adobe (add) royalties for CTP (8Up)

- **501R49715 Brisque to TS VLF Quantum V DCK**

  S/W CD, PRINTCONSOLE 2.1

  BRISQ2TS FOR DIRECT CONNECTIVITY

  KIT, ROTATION 2 BOARD 128MB

  TSP BOARD ONLY

  License Brisque Staccato 20

  Adobe (add) royalties for CTP (VLF)

- **501R49948 Brisque to TS 400/800 Quantum V DCK for Performance Dual and F50**

  S/W CD, PRINTCONSOLE 2.1

  BRISQ2TS FOR DIRECT CONNECTIVITY

  KIT, ROTATION 2 BOARD 128MB

  TSP BOARD ONLY

  License Brisque Staccato 20

  Adobe (add) royalties for CTP (8Up)

  KIT, U/G 512MB MEM. FOR 6F1/F50.



Note: All DCKs include the BRISQ2TS FOR DIRECT CONNECTIVITY kit which contains:
SCSI 3 (68PIN PLGX2) L=20M WIT.
BRISQUE 4.0 Quick start (Translated)
TURBO SCREENING WBT CD
TSP Board only
Brisque AGENT S/W DOC TS V
SUPPORT KIT BRISQUE V.4.0.97
ULTRA SCSI DIFF PCI ADAPT. 4-U.

Documentation and Training



For information about the installation procedure for Brisque to Trendsetter V speed range, see *Brisque to Trendsetter V models Direct Connectivity Guide, 399Z3R310A*.

This document is also available on the **Brisque Agent** CD-ROM and on TechPlanet at:

http://techplanet.creo.com/software_solutions/workflow_software/direct_connect/content/docs/Brisque_Trendsetter_V_InstGuide.pdf

Prerequisites

- Brisque Version 4.0.97 (EP) or later
- Brisque platform 6F1
- Minimum 1GB RAM size (additional 512MB RAM for 6F1-2CPU configuration is included in the appropriate DCKs)
- DCK kit components:
  - TSP boards with comp level "M" - 503D03465M
  - Print Console v2.1.1.24 or later
  - BrisqueAgent 1.0.46 or later

Known Bugs and Limitations

- All expose operations with the default **PlateExp** template fail with error 5408.

  Workaround: Create templates with the correct setting and use the Expose operation only via those templates.

- Layout Arrange is not supported.
- In the Plate set list of the **PlateExp** template, there is no Red/Green text. All plate sets appear in the template with Black text.
- Wrong exposure when modifying an existing template. When changing the plate type in the template from **Negative** to **Positive**, the Pages are exposed in the wrong exposure type (**Negative**).

  Workaround: Don't modify the plate set in an existing template. Create a new template from scratch.

Before Loading the Software

- The **Loading a Full Version** option maintains the Brisque's current configuration (Hot Folders, Templates, Screen sets, Network Settings, and so on). However, it is always recommended to back up your configuration (SciSMIT, Backup and Restore, Save Configuration To dataVolume) prior to updating any software on the Brisque.
- Loading a full version reverts Brisque Preferences (**Prefs.** icon in the **Utilities** panel) back to the defaults.

  Write down any changes to the defaults and re-enter them after loading the software.

- Loading a full version reverts the stand-alone operations in the **Operations** and **Output** panels of the Brisque Launch Pad back to the defaults. That is, any customization of these panels is cancelled.

  Write down any changes to the defaults and re-enter them after loading the software.

- Queue Manager is emptied following loading of a full version. All waiting, failed, finished, and On-Hold jobs are deleted from the queue.

Loading Instructions

A. Loading a full software version

This option enables you to install the new Brisque version. During the installation, all current packages including updates are deleted and the new Brisque version is installed.



Important: Sometimes, when the Brisque is connected to an external disk tower of any kind, loading may take up to an additional 2 hours. It will seem as if nothing is happening for long periods of time, but the system is actually working fine. (the LEDs on the external disks will blink shortly every once in a while).
Do not attempt to stop the loading process. It should end successfully. Stopping the loading process will result in the necessity of a cold-start installation.

The following existing Brisque Version 4.0 updates (available in CD#2) should not be installed on top of 4.05.15. If you have them installed already on your Brisque version 4.0.97, do not reinstall them after upgrading to 4.05.15.:

- UpdLotemSpectrum.JAR
- Upd_Brisque4_ExposeJRE
- Upd_Versioning_97_1
- Upd_Brisque4_97_Bitmap
- Upd_Brisque4_97_PlateExpInv
- Upd_Brisque4_97_Spectrum
- Upd_Brisque4_97_Staccato
- Upd_Brisque4_97_Packaging
- Upd_Brisque4_Dolev800V3
- UpdTSPBoard
- Upd_Brisque4_Flex
- Upd_Brisque4_97_Output
- Upd_Brisque4_97_TiffArrange

To load a full software version:

1. Exit the Brisque application and reboot the Brisque.
2. Log on as **root** and type your password (**ripro**).
3. At the command prompt, type **scismit** and press ENTER to access the SciSMIT main menu.
4. From the SciSMIT main menu, select **Software Handling** and then **Loading Full Software Version**.
5. Insert the **Brisque version 4.0.97 Product 1 of 2** CD (from the "blue box") in the CD-ROM drive and press ENTER. An `Are you sure...?` message appears.
6. Press ENTER.

   This process takes approximately 25 minutes to complete.



   Note: Remember to leave the front door open since the CD will be ejected automatically.

   When ready, the following message appears on the screen:

   ```
   Please insert "Brisque Product 2" CD and press Enter to
   continue...
   ```

7. Remove the **Brisque version 4.0.97 Product 1 of 2** CD from the CD-ROM drive, insert the **Brisque version 4.0.97 Product 2of 2** CD and press ENTER.

   This process takes approximately 5 minutes to complete. Upon completion the system reboots.

   After reboot the Console login appears:

   ```
   AIX Version 4
   (c) Copyrights by IBM and others 1982, 1996
   Console login:
   ```

8. Remove the **Brisque version 4.0.97 Product 2of 2** CD from the CD-ROM drive.
9. Proceed with the *B. Load the 4.05.15 Update* procedure on *page 8*.

B. Load the 4.05.15 Update

To update the Brisque software package to 4.05:

1. Exit the Brisque application and reboot the Brisque.
2. Log on as **root** and type your password (**ripro**).
3. At the command prompt, type **scismit** and press ENTER to access the SciSMIT main menu.
4. Insert the **Brisque Update 4.05.15 for TS V** CD in the CD-ROM drive.
5. From the SciSMIT main menu, select **Software Handling** and then **Update Software Packages.**
6. Press F4 to display the list of optional updates.
7. Make sure **Upd_Brisque4_05** is selected and press ENTER three times.

   Upon completion the system automatically reboots.

   After reboot the Console login appears:

   ```
   AIX Version 4
   (c) Copyrights by IBM and others 1982, 1996
   Console login:
   ```
8. Log on as **cdesci.**
9. Remove the **Brisque Update 4.05.15 for TS V** CD from the CD-ROM drive.
10. From the Brisque Launch Pad **Utilities** panel, double-click the **Station Info** icon, then click the **More Info** button to verify that **Upd_Brisque4_05 4.0.97.15** is listed.



Important: Do not use the default **PlateExp** template. It is recommended to create a basic Plate Expose template and use the Expose operation only with this template.