8 July, 2003

New Brisque Part Numbers

Brisque Description	Based on IBM platform	Old part number	New part number
BRISQUE PRO (43P-150)	Tiger (43P)	501S1L811**C**	501S1L811**D**
BRISQUE EXPOSE (43P-150)	Tiger (43P)	501S3D067**B**	501S3D067**C**
BRISQUE ACCESS (43P-150)	Tiger (43P)	501S3E843**B**	501S3E843**C**
BRISQUE IMPOSE 400 (43P-150)	Tiger (43P)	010-00101**A**	010-00101**B**
BRISQUE IMPOSE (44P-170)	Hammerhead (44P)	501S1L817	501S1L817**A**
BRISQUE EXPOSE (44P-170)	Hammerhead (44P)	501S1L820	501S1L820**A**
BRISQUE 44P-170 TRADE-IN	Hammerhead (44P)	501S4E203**A**	501S4E203**B**
BRISQUE PRO (44P-170)	Hammerhead (44P)	501S4E196	501S4E196**A**
BRISQUE ACCESS (44P-170)	Hammerhead (44P)	501S4E260	501S4E260**A**
BRISQUE IMPOSE DUAL-6F1 600MHZ	6F1 (Dual)	501S1L973**A**	501S1L973**B**
BRISQUE 6F1-2W TRADE-IN 600MHZ	6F1 (Dual)	501S4E204**A**	501S4E204**B**
BRISQUE PRO DUAL-6F1 600MHZ	6F1 (Dual)	501S4E197**A**	501S4E197**B**
BRISQUE EXPOSE DUAL-6F1 600MHZ	6F1 (Dual)	501S4E261	501S4E261**A**
BRISQUE IMPOSE QUAD-6F1 600MHZ	6F1 (Quad)	501S1L974**A**	501S1L974**B**
BRISQUE 6F1-4W TRADE-IN 600MHZ	6F1 (Quad)	501S4E205**A**	501S4E205**B**
BRISQUE PRO QUAD-6F1 600MHZ	6F1 (Quad)	501S4E198**A**	501S4E198**B**
BRISQUE IMPOSE SIXT (6F1) 750MHZ	6F1 (Sixt)	501S1L975	501S1L975**A**
BRISQUE 6F1-6W TRADE-IN 750MHZ	6F1 (Sixt)	501S4E206**A**	501S4E206**B**
BRISQUE PRO SIXT (6F1) 750MHZ	6F1 (Sixt)	501S4E199	501S4E199**A**