Lotem ThermoFlex Update

(Upd_Brisque4_Flexo – 4.0.97.5 and **Upd_Brisque4_97_ExposeJRE – 4.0.97.4)**

(Size 38980KB)

Read Me Contents:

A. Who should load this update?
B. What this update includes?
C. Minimum Requirements
D. Additional Notes
E. Loading Instructions

A. Who should load this update?

Customers who need to use the FlexoTable application.
The FlexoTable application enables the service engineer to optimize and clear the Screen Set from undesired effects, by determining the optimum number of laser beams the ThermoFlex platesetter will use to expose the separation. The application searches the table for the specific Screen Set parameters. When found, it returns the optimal number of beams for the exposure.

B. What this update includes?

The update contains two packages:

1. **Upd_Brisque4_Flexo – 4.0.97.5**
2. **Upd_Brisque4_97_ExposeJRE – 4.0.97.4**

C. Minimum Requirements:

Should be loaded on top of Brisque version 4.0.97 with the mandatory updates **Upd_Brisque4_97_1 (4.0.97.18)** and **Upd_Brisque4_97_ResetBoard (4.0.97.4)**, both exist on Version 4.0.97 2 of 2 CD and are automatically loaded during the Version 4.0.97 installation process.
Select **Station Info > More Info** and make sure you have the following packages prior to installation:
Upd_Brisque4_97_1 (4.0.97.18)
Upd_Brisque4_97_ResetBoard (4.0.97.4)

D. Additional Notes

1. This update should be loaded/reloaded on top on any other update.
2. Release notes can be found on the TechPlanet:
   http://techplanet.creo.com/software_solutions/workflow_software/brisque/content/memos/v4-0-97-thermoflex.htm

E. Loading Instructions

Note: If you've previously downloaded the **update.tar** script and created the **.updates** folder, start at **step3**.

1. Create a folder on the Brisque named **.updates** under the **FIRST** dataVolumes (example: **/dataVolumes/brisque1.1.0/.updates**
   Note: In order to see the **.updates** folder from the Brisque, click View and make sure Show Hidden Objects is selected (or Ctrl + S).
2. Copy/download the script **update.tar** from:
   ftp://ftpcsa.creo.com/brisque/download/V4/Updates/4.0.97/script/ into the **.updates** folder.
3. Copy/download **Upd_Brisque4_Flexo_5.tar** from:
   ftp://ftpcsa.creo.com/brisque/download/V4/Updates/4.0.97/Flexo-5/ into the **.updates** folder.
4. Logout from the Brisque application.
5. Login as root/ripro.
   Note: If you've previously installed the **update.tar** script, continue with **step 7**.
6. Type: ***tar -xvf /dataVolumes/brisque1.1.0/.updates/update.tar*** and hit **Enter**.
7. Type: ***update.sh*** and hit **Enter**.
8. Type a period (**.**) in **INPUT device** field and hit **Enter**.
9. Hit [**F4**] and use [**F7**] to select both **Upd_Brisque4_Flexo** and **Upd_Brisque4_97_ExposeJRE** and hit **Enter**.
10. Hit **Enter** twice.
11. After the **OK** message, hit the [**F10**] key.
12. Type: **y** and hit **Enter** for automatic reboot.

After rebooting, login as ***cdesci*** and go to **Station Info** --> **More Info** to confirm that:
Upd_Brisque4_Flexo.obj 4.0.97.5 and **Upd_Brisque4_97_ExposeJRE.obj 4.0.97.4** are listed.