Clean Table Vacuum Generators

Applies to ThermoFlex

Background Vacuum generators may over time, accumulate debris in the venturi or silencer. This debris will degrade the performance of the generator, and reduce the plate holding capacity of the table vacuum system.

Tools and parts Pliers

Steps

1. Open the ThermoFlex table
2. Unscrew the air outlet cover (cylindrical aluminum cover with holes in it) for the vacuum generators located on the underside of the table. These should be removable by hand, but a pair of pliers may be required.
3. Remove the white porous filter/silencer and clean out any dirt particles.
4. Repeat for the rest of the vacuum generators (total of 3).

Notes

Technical contact M. Herbert (mherbert@creo.com)

Date submitted 15 Aug 1999

Date modified 15 Aug 1999