Servicing the Flash Cover Detent Components

Context

☑ ThermoFlex

Background

Various positions along the flash cover travel are defined by detents. The lock cylinder plunger and a detent bar may require maintenance if they become worn.

Tools and parts

- 3mm Allen Key

Steps

1. Remove the flash cover (see flash cover removal procedure).
2. Inspect the nylon acorn nut for damage.

   Replace if necessary.
3. Inspect the detent bar located on the underside of the flash cover for damage

   Replace if necessary.
4. Re-install the flash cover.