Replace Drum Vacuum Drive fuse(s)

Applies to

ThermoFlex

Background

When it appears that one of the Drum Vacuum Drive (DVD) fuses have blown, follow this procedure to locate and replace the defective fuse.

Tools and parts

- Fuses (13-5009)
- Multimeter

Steps

Caution: Ensure that all power to the Drum Vacuum Drive is disconnected and that the breaker to the assembly is opened.

1. Using the 2.5mm Allen key, remove the 24 screws that hold the Drum Vacuum Drive Assembly cover in place.
2. Gently lift the cover off and away from the Drum Vacuum Drive Assembly, placing it on a clean surface (take care not to damage the cover).
3. Before proceeding, use the multimeter to ensure that the power is off.
4. Measure the fuse impedances with the multimeter to determine which fuse is damaged.
5. Replace the damaged fuse(s) with part number 13-5009.

Notes

Technical contact

Ted Nivolianitis

Date submitted

15 Nov 1999

Date modified

10 Dec. 1999.