Accessing the fan box

Description The fan box must be opened to replace the intake filter and desiccant.

Context ☑ Trendsetter 3230 (TS4 Version)

Steps

1. Use a flathead screwdriver to loosen the fan box panel screws.
2. Tilt the panel toward you then lift off its locating pins.