Adjusting the 3230 (TS4), 3244 (TS8) TEC backbone actuator speed

Context

- ☑ Trendsetter 3230 (TS4 Version)
- ☑ Trendsetter 3244 (TS8)

Steps

1. Ensure that the TEC cylinder rod ends are adjusted properly.
2. Adjust the speed controls on one side to balance motion towards the drum only.
3. Make sure that the TECs are on the backbone.

   You can write a script file to cycle the TEC backbone up and down while you make the adjustment.

   When the backbone comes down evenly, there is a loud noise as the TECs impact against the drum. This is due to the attraction of the magnets to the clamps.

Notes

The speed controls for the trailing edge down are adjusted differently on the VLF than the 3244 engine.