Accessing the backplane

Context

- ☑ VLF Trendsetter
- ☑ ThermoFlex

Background

Backplane access may be necessary to check connections. The backplane is at the rear of the card cage inside the power box.

Steps

1. Open the power box. See Accessing the power box.
2. Remove the panel at the rear of the card cage using a flat head screwdriver.