Accessing the card cage

Context

- ☑ VLF Trendsetter
- ☑ ThermoFlex

Background

Card cage access may be necessary to inspect or replace boards. The card cage is inside the power box.

Steps

1. Open the right side panel (VLF Trendsetter) or left side panel (ThermoFlex).
2. Pull the two black buttons on the right side of card cage.
3. Open the card cage door.

Notes

The card cage should only be accessed by Creo service personnel.