


J1	Drum command in (from MCF)	J9	Power to drum driver
J2	Drum hall effect	J10	Drum vacuum power in
J3	To drum driver	J11	Drum vacuum power in
J4	Solenoids, interlock, on switch, vibration	J12	Drum vacuum power in
J5	Solenoids	J13	Power in
J6	Power & Communication	J14	Spare
J7	Spare	J15	To transformer
J8	Loading vacuum power out	J16	From transformer