```
5981ENG>> Safety
Safety Loop Status
-------------------------
Emergency stop switch:        Off
Away side panels:             Off
Hood:                         Off
Lock Solenoids:               Off
Home side panels:             Off
Center panels:                Off
Center Table:                 Off
Safety override (key switch)  Off
Safety loop status            Off
Safety write laser            Off
*** Command Complete
```

2, 3, 4
g
a
1, 7, 8
6
5

