# Enabling film imaging on Trendsetter MCE

**Applies to**

☑ Trendsetter® 400/800 II

**Background**

Trendsetter 400/800 II devices include the option for imaging film, but usually are shipped with film handling turned off. This procedure details how to enable film imaging.

**Tools and parts**

- Service Shell

**Steps**

1. In Service Shell, **`access dev`**
2. Use **`feature list`** to check to see if film imaging is already enabled.
3. To enable film imaging:
   - **`feature`** <password> **`20`** <xxxx>
     where <xxxx> is:
     **`5930`** for S-speed
     **`9420`** for F-speed
     **`18000`** for V-speed

   <password> is available from the Response Centre RC2 team if needed

**Notes**

These features are currently controlled by password. Creo Feature Licensing in CR5.0 will replace this control.

**See also**

- Thermal Film Media pages at http://techplanet.creo.com/consumables/media/nav/thermal_film.htm

**Technical contact**

Doug Jeffery

**Date submitted**

28 April 2005

**Date modified**

02 May 2005