Connectivity
Installation Guide

English

Prinergy to Lotem Quantum SCSI

www.creo.com

SCSI connectivity installation guide
Direct connection Prinergy - LotemQuantum800 and LotemQuantum800 MCU

DELL hardware	SCSI adapter	Cable	Comments	What to order?
DELL 2400L	Use an extra SCSI controller: # Name of the SCSI adapter: Adaptec 39160 Dual Channel LVD # Partnumber of the card: 94-3220 To be installed in PCI slot 3 or 4	Connect a small black adapter cable to one of the 2 SCSI channels of the Adaptec. # Name of the black adapter cable: VHD68M-Ext 68F # Part number of the adapter cable: 16-3907 From this black adapter, you will need to connect the long 15m SCSI cable to the device. # Part number of this cable: 16-4527	Use the standard W2K driver in order to install the SCSI controller.	# Connectivity Kit: PN 22-0193A # Adaptec 39160: PN 94-3220 # Adapter cable: PN 16-3907 #15m SCSI cable: PN 16-4527
DELL 2400H	Use an extra SCSI controller: # Name of the SCSI adapter: Adaptec 39160 Dual Channel LVD # Part number of the card: 94-3220 To be installed in PCI slot 3 or 4	Connect a small black adapter cable to one of the 2 SCSI channels of the Adaptec. # Name of the black adapter cable: VHD68M-Ext 68F # Part number of the adapter cable: 16-3907 From this black adapter, connect the long 15m SCSI cable to the device. # Part number of this cable: 16-4527	Use the standard W2K driver in order to install the SCSI controller.	# Connectivity Kit: PN 22-0193A # Adaptec 39160: PN 94-3220 # Adapter cable: PN 16-3907 #15m SCSI cable: PN 16-4527
DELL 2500L	Use the on-board SCSI controller. Only 1 SCSI connection on the back will be available to connect to the device.	From the internal SCSI connection, connect the long 15m SCSI cable to the device. # Part number of this cable: 16-4527	In order to be able to use this on-board controller please follow this procedure: # Press F2 during the boot of the DELL # Go to "Integrated devices" # Select Embedded RAID controller # Make sure that Channel B is set to "SCSI". # Save and restart the system.	# Connectivity Kit: PN 22-0193A
DELL 2500H	Use the on-board SCSI controller. Only 1 SCSI connection on the back will be available to connect to the device.	From the internal SCSI connection, connect the long 15m SCSI cable to the device. # Part number of this cable: 16-4527	In order to be able to use this on-board controller please follow this procedure: # Press F2 during the boot of the DELL # Go to "Integrated devices" # Select Embedded RAID controller # Make sure that Channel B is set to "SCSI". # Save and restart the system.	# Connectivity Kit: PN 22-0193A
DELL 2500V	Use and extra SCSI controller: # Name of the SCSI adapter: Adaptec 39160 Dual Channel LVD # Partnumber of the card: 94-3220 To be installed in PCI slot 3, 4 or 5	Connect a small black adapter cable to one of the 2 SCSI channels of the Adaptec. # Name of the black adapter cable: VHD68M-Ext 68F # Part number of the adapter cable: 16-3907 From this black adapter, connect the long 15m SCSI cable to the device. # Part number of this cable: 16-4527	Use the standard W2K driver in order to install the SCSI controller.	# Connectivity Kit: PN 22-0193A # Adaptec 39160: PN 94-3220 # Adapter cable: PN 16-3907 #15m SCSI cable: PN 16-4527

SCSI connectivity installation guide
Direct connection Prinergy - LotemQuantum800 and LotemQuantum800 MCU

DELL hardware	SCSI adapter	Cable	Comments	What to order?
DELL 4400	Use and extra SCSI controller: # Name of the SCSI adapter: Adaptec 39160 Dual Channel LVD # Partnumber of the card: 94-3220 To be installed in PCI slot 3, 4 or 5	Connect a small black adapter cable to one of the 2 SCSI channels of the Adaptec. # Name of the black adapter cable: VHD68M-Ext 68F # Partnumber of the adapter cable: 16-3907 From this black adapter, you will need to connect the long 15m SCSI cable to the device. # Partnumber of this cable: 16-4527	Use the standard W2K driver in order to install the SCSI controller.	# Connectivity Kit: PN 22-0193A # Adaptec 39160: PN 94-3220 # Adapter cable: PN 16-3907 #15m SCSI cable: PN 16-4527
DELL 6400	Use the on-board SCSI controller. 2 SCSI connections on the back will be available to connect to the device. You can take the SCSI connection that is free.	From the internal SCSI connection, connect the long 15m SCSI cable to the device. # Part number of this cable: 16-4527		# Connectivity Kit: PN 22-0193A