Gravure Update 6

(Upd_Brisque41_Gravure 4.1.76.6)

(Size **32256** KB)

Read Me Contents:

A. Who should load this update?
B. What this update includes?
C. Minimum Requirements.
D. Loading Instructions.

A. Who should load this update?

Currently should be in use only be Brisque IGS users.

B. What this update includes?

The update includes new features for Gravure:

- Support for Rotation board
- New Orientation Input (Rotate 90) in CylExp dialog
- New 27 Home Factory Gravure screens of 2 types (GStandxxxx, GSolidxxxx)
- Gstand and Gsolid new angles types in Screen Set Dialog for Gravure
- Outline support for Wrap images in Packaging Jobs
- High Def. Pop Up for selection of TSP mode: X4 X2 x1 in Screen2GO dialog
- Save configuration to dataVolume create Archive & Compress file: config_save_archive.tar.Z

Corrections for:

- Expose of big page in Impo Job, problem from Think
- Fix of outline with Negative text near the seam
- Improve Quality of screens for Gratio 35
- Swap Wrong & Right when using Rotate 90
- Save configuration to dataVolume will not fail in case of missing config files
- Include all the corrections that exist in previous Gravure Update 4 and 5

C. Minimum Requirements:

Should be loaded on top of Brisque Version 4.1.76 with Brisque Output Update 4.1.76.5 loaded on Brisque IGS stations.

Copy/download **Upd_Brisque41_Output_5.tar** from:
ftp://cilftp.creo.com/PWS/brisque/download/V41/Updates/4.1.76/Output/

IMPORTANT: New license with Gravure_Tools option is required – Purchasable option

D. Loading Instructions

The update can be installed via a new feature **Load Update** that allows you to install updates to your Brisque software from either a CD or dataVolumes and to start the installation process without having to log off from the Brisque applications.
For more information please refer to the **What's New in 4.1** document

1. Create a folder on the Brisque named **.updates** under the **FIRST** dataVolumes (example: **/dataVolumes/brisque1.1.0/.updates**
   Note: In order to see the **.updates** folder from the Brisque, click View and make sure Show Hidden Objects is selected (or Ctrl + S).
2. Copy/download **Upd_Brisque41_Gravure_6.tar** from:
   ftp://cilftp.creo.com/PWS/brisque/download/V41/Updates/4.1.76/Gravure/ into the **.updates** folder.
3. From the Launch Pad, open the Services menu and double-click on **Load Update** icon.
4. Type **root** and enter your password [ripro] followed by Enter.
5. Please wait a few seconds and a new **Load Update** application will be launched.
6. Select the **Install** tab.
7. Select the **DataVolume** button. The **Upd_Brisque41_Gravure** will appear in the list.
8. Choose the update from the list and click **Install**. The system will reboot before & after the Update loading.
9. After rebooting, login as ***cdesci*** and go to **Station Info** --> **More Info** to confirm that:
   Upd_Brisque41_Gravure 4.1.76.6 is listed.