ExportPS Update

(Upd_Brisque4_97_ExsportPS - 4.0.97.3)

(Size 1870KB)

Read Me Contents:

A. Who should load this update?
B. What this update includes?
C. Minimum Requirements.
D. Loading Instructions.

A. Who should load this update?

Customers who is using ExportPS to Agfa Taipan.

B. What this update includes?

The Screen Angle in the ExportPS file (2.30, created on V4) is not recognized by Agfa Taipan (CPSI 3010.105.r1). Each plate including Spots is rendered at the Black angle (45 deg).

C. Minimum Requirements:

Should be loaded on top of Brisque version 4.0.97 with the mandatory updates **Upd_Brisque4_97_1 (4.0.97.18)** and **Upd_Brisque4_97_ResetBoard (4.0.97.4)**, both exist on Version 4.0.97 2 of 2 CD and are automatically loaded during the Version 4.0.97 installation process.
Select **Station Info > More Info** and make sure you have the following packages prior to installation:
Upd_Brisque4_97_1 (4.0.97.18)
Upd_Brisque4_97_ResetBoard (4.0.97.4)

D. Loading Instructions

Note: If you've previously downloaded the **update.tar** script and created the **.updates** folder, start at **step 3**.

1. Create a folder on the Brisque named **.updates** under the **FIRST** dataVolumes (example: **/dataVolumes/brisque1.1.0/.updates**
   Note: In order to see the **.updates** folder from the Brisque, click View and make sure Show Hidden Objects is selected (or Ctrl + S).
2. Copy/download the script **update.tar** from: ftp://ftpcsa.creo.com/brisque/download/V4/Updates/4.0.97/script/ into the **.updates** folder.
3. Copy/download **Upd_Brisque4_97_ExportPS_3.tar** from: ftp://ftpcsa.creo.com/brisque/download/V4/Updates/4.0.97/ExportPS-3/ into the **.updates** folder.
4. Logout from the Brisque application.
5. Login as root/ripro.
   Note: If you've previously installed the **update.tar** script, continue with **step 7**.
6. Type: ***tar -xvf /dataVolumes/brisque1.1.0/.updates/update.tar*** and hit **Enter**.
7. Type: ***update.sh*** and hit **Enter**.
8. Type a period (**.**) in **INPUT device** field and hit **Enter**.
9. Hit [**F4**], select **Upd_Brisque4_97_Export_PS** and hit **Enter**.
10. Hit **Enter** twice.
11. After the **OK** message, hit the [**F10**] key.
12. Type: **y** and hit **Enter** for automatic reboot.

After rebooting, login as ***cdesci*** and go to **Station Info** --> **More Info** to confirm that:
Upd_Brisque4_97_Export_PS.obj 4.0.97.3 is listed.